MITSUBISHI

Service Manual



MODEL

CT-37C2EDT

MITSUBISHI ELECTRIC CORPORATION

SPECIFICATION

Reception System	:	CCIR-B,G,I,L
Colour System	:	PAL/SECAM/3.58NTSC/4.43NTSC
Reception Freqeuncy	:	VHF : 44~68, 174~230MHz UHF : 470~862MHz
Mains Input	:	AC230V; 50Hz
Power Consumption	:	170W
Aerial Input	:	75Ω unbalanced
Intermediate Frequency	:	Video : 34.47/38.9MHz Sound : 32.4/32.9/33.16/33.4MHz Colour : 34.47/38.9MHz
Audio Output	:	30W+30W (Music Power)
Speaker	:	ø 100mm 2pcs
Chassis	:	EURO 9
Picture Tube	:	A48JWH10X 37" 110° Deflection
Cabinet Dimensions	:	959(W) x 727(H) x 593(D)mm
Weight (Approx.)	:	86.2kg

SAFETY PRECAUTIONS

NOTICE : Observe all cautions and safety related notes located inside the receiver cabinet and on the receiver chassis.

WARNING

1. An isolation transformer should be used between the television receiver and the AC supply point before any test/service is performed on a live chassis television receiver.
2. Operation of these receivers outside the cabinet or with the cover removed, involves a shock hazard from the receiver power supplies. Work on the receiver should not be attempted by anyone who is not throughly familiar with precautions necessary when working on high voltage equipment.
3. Do not install, remove or handle the picture tube in any manner unless shatter – proof goggles are worn. People not so equipped should be kept away while the picture tube is being handled. Keep the picture tube away from the body while handling.
4. When service is required, observe the original lead dressing. Extra precaution should be given to assure correct lead dressing in the high voltage area. Where a short – circuit has occurred, replace those components that indicate evidence of overheating.

LEAKAGE CURRENT COLD CHECK

Before returning the receiver to the customer, it is recommended that the leakage current be measured according to the following methods.

With the AC plug removed from the AC source, place a jumper across the two AC plug prongs. Turn the receiver AC switch on. Using an OHM-METER, connect one lead to the jumpered AC plug and touch the other lead to each exposed metal part (antennas, screwheads, etc.), particularly any exposed metal part having a return path to the chassis. Exposed metal parts having a return path to the chassis should have a minimum resistance reading of 4 meg ohm. Any resistance below this value indicates an abnormality which requires corrective action.

CABINET PARTS



Fig. 1

CONTROL LOCATION



Fig. 2

CONNECTORS



① AERIAL SOCKET
② EXTERNAL LOUDSPEAKER CONNECTOR
③ S-VIDEO INPUT CONNECTOR
④ S-VIDEO AUDIO INPUTS
⑤ AV1 SCART SOCKET
⑥ AV2 SCART SOCKET
⑦ STEREO/MONO SWITCH

SCART SOCKET CONNECTIONS

MODE / PIN	AV1	AV2
1	AUDIO OUT R	
2	AUDIO IN R	
3	AUDIO OUT L	
4	AUDIO EARTH	
5	BLUE EARTH	EARTH
6	AUDIO IN L	
7	BLUE IN	NOT CONNECTED
8	FUNCTION SWITCH	
9	GREEN EARTH	EARTH
10	NOT CONNECTED	
11	GREEN IN	NOT CONNECTED

MODE / PIN	AV1	AV2
12	NOT CONNECTED	
13	RED EARTH	EARTH
14	EARTH	
15	RED IN	S CHROMA IN
16	RGB STATUS (BLANKING)	NOT CONNECTED
17	VIDEO OUT EARTH	
18	VIDEO IN EARTH	
19	VIDEO OUT	
20	VIDEO IN	
21	SOCKET EARTH	

Fig. 3

Using Extension cord jig

Using the Extension cord (Part No. 859C431O30) for servicing the PCB TEXT, the PCB YUV and the PCB DBF.

REPLACING THE PICTURE TUBE

1. Remove the left and right speakers.
2. Remove 24 screws retaining the rear cover. (Fig. 4-1)
3. Remove the main PC boards.
4. Remove the lead clamper and connector anode cap.
5. Remove 4 screws retaining the shield cover. (Fig. 4-2)



Fig. 4-1.



Fig. 4-2.



6. To protect the front surface of the CRT from damage, prepare a soft sheet, and lay the set on that sheet. Then, remove the four CRT lock nuts, using the T driver (JIG No. 859C358020). (Fig. 4-3)
7. Mount the set on the base so that the centre of picture tube is aligned with the centre of the base. Then, lower the cabinet slowly. (Fig. 4-4)
8. Replace the CRT with new one. For installation of the picture tube, reverse the above procedure. (Fig. 4-5)



Fig. 4-3.



Fig. 4-4.



Fig. 4-5.

Using Extension cord jig

Using the Extension cord (Part No. 859C431O30) for servicing the PCB TEXT, the PCB YUV and the PCB DBF.

REPLACING THE PICTURE TUBE

1. Remove the left and right speakers.
2. Remove 24 screws retaining the rear cover. (Fig. 4-1)
3. Remove the main PC boards.
4. Remove the lead clamper and connector anode cap.
5. Remove 4 screws retaining the shield cover. (Fig. 4-2)



Fig. 4-1.



Fig. 4-2.



6. To protect the front surface of the CRT from damage, prepare a soft sheet, and lay the set on that sheet. Then, remove the four CRT lock nuts, using the T driver (JIG No. 859C358020). (Fig. 4-3)
7. Mount the set on the base so that the centre of picture tube is aligned with the centre of the base. Then, lower the cabinet slowly. (Fig. 4-4)
8. Replace the CRT with new one. For installation of the picture tube, reverse the above procedure. (Fig. 4-5)



Fig. 4-3.



Fig. 4-4.



Fig. 4-5.

ITC adjustment

Purity and Convergence

Before adjusting the INTEGRATED TUBE COMPONENT, warm up the Receiver for more than an hour with a monochrome signal applied, to allow normal beam current flow.
Degauss not only the front and rear of the CRT but also the external magnetic shield, CRT holder, etc. (Insufficient degaussing causes magnetization, giving an unfavourable effect on colour purity adjustment.)

Purity and Convergence adjustments should be performed in the following sequence when replacing either the Picture Tube, Deflection Yoke, or Purity & Convergence Magnetic Assembly.

Note 1: The picture tube provided as a service spare part replacement is supplied in the form of assembly with Picture Tube, Deflection Yoke and Purity and Convergence magnetic assembly attached.
As a rule, Purity Convergence adjustment have already been preset at the factory, so that the final adjustment procedure only is required.

Note 2: When replacing either the Deflection Yoke or Purity and Convergence Magnetic Assembly, follow procedures (1) through (5).

Note 3: If purity adjustment only is required, with no components replaced, follow "FINAL ADJUSTMENT".

Procedure

(1) Remove the deflection yoke and rubber wedges from the picture tube cone, take care not to strike or scratch the cone surface.
(2) Clean any remaining cement off the deflection yoke and the surface of the picture tube cone.
(3) Put the deflection yoke on the neck of the picture tube, fully forward against cone.
(4) Put the Purity & Convergence assembly on the neck of the picture tube so that the distance between the 6-pole magnet and the base of the tube is 1.81±0.04 inches(46±1.0mm) as shown in Fig. 5-1, and tighten screw by hand.
(5) Demagnetize the front and sides of the receiver with a degaussing coil.



LENGTH
46±1.0 mm 1.81±0.04 inches

Fig. 5-1

Preliminary Adjustment

1. Purity

(1) Tune receiver to a monochrome signal.
(2) Short-circuit the base and emitter of B-OUT transistor to produce yellow raster.
(3) With the deflection yoke positioned fully forward, adjust the purity magnet so that the yellow bar is at the centre of the screen with normal vertical centreing.
(4) Slide the deflection yoke slowly backwards to produce a uniform yellow raster.
(5) Remove the shorting link on B-OUT transistor.
(6) Short-circuit the base and emitter of corresponding two transistors as indicated in Table 1 to produce green, red and blue rasters and to verify their purity, and fasten the DY screw on the deflection yoke temporarily.
(7) Remove the shorting leads from respective transistors.



Fig. 5-2

Table 1
Transistors to be Shorted Base to Emitter to Produce Primary Colour.

Transistor / Raster	R – OUT	G – OUT	B – OUT
Red	Open	Short	Short
Green	Short	Open	Short
Blue	Short	Short	Open

2. Static Convergence Adjustment

(1) Tune the receiver to a crosshatch signal.
(2) Set the BRIGHTNESS and CONTRAST controls to centre position.
(3) Adjust the degree of angle between the tabs of the 4-pole magnet and the angular position to converge the "B" and "R" beams of the green at the centre on the screen.
[Refer to Fig. 5-3(b)]
(4) Adjust the degree of angle between the tabs of the 6-pole magnet and the angular position to converge the "B" and "R" beams to the "G" beam at the centre of the screen.
[Refer to Fig. 5-3(c)]
(5) If necessary, repeat the above steps.



Fig. 5-3(a) Before Adjustment

Fig. 5-3(b) Adjustment by 4-pole Magnet

Fig. 5-3(c) Adjustment by 6-pole Magnet

Note:

* The 4-pole magnet moves "B" and "R" beams in equal distances but opposite directions.
* The 6-pole magnet moves "B" and "R" beams in the same direction and distance.
* The "G" beam is not movable by the 4-pole and 6-pole magnets.

3. Focus Adjustment

(1) Supply a grey scale signal with window.
(2) Observing around the vertical line, adjust FOCUS control for best overall focus.
Refer to Focus of electrical adjustment.

Final Adjustment

1. Purity

(1) Tune receiver to a monochrome signal.
(2) Short-circuit the base and emitter of B-OUT transistor to produce yellow raster.
(3) Loosen the Deflection Yoke screw and move it forward. Make certain that the yellow bar is at the horizontal centre. If necessary, adjust purity magnets to centre it.
(4) Slide the Yoke backwards to produce a uniform yellow raster.
(5) Short-circuit the base and emitter of corresponding two transistors as indicated in Table 1 to produce green, red and blue rasters and to verify their purity, and fasten the DY screw on the deflection yoke temporarily.
(6) If necessary, repeat above steps.
(7) Tighten the Yoke in position.
(8) Remove the shorting leads from respective transistors.
(9) Fix the yoke in position using the DY screws.



Fig. 5-4

Note: When adjusting the Deflection Yoke position, never touch any portion of the yoke other than the screw. Do not touch the purity ring magnete unless absolutely necessary, in which case carry out the preliminary purity adjustment procedures again.

Screen corner landing compensation

※ The steps described below are for correcting outward colour beam divergence at screen corners. Take reversal placement of the magnetic pieces for correcting inward divergence.
(1) Degauss the unit with its own degauss system.
※ Do not use any degaussing coil other than the built-in degaussing coil since the external coil may fail degaussing and worse, will magnetize the TV set.
(2) Receive the red, green or blue signal.
(3) Make sure that the colour other than the received colour does not appear at a corner of the screen. If appears, attach magnetic pieces (up to 3 pieces at a position) on the funnel of the CRT so that the colour disappears.(Part No. of the magnet : 461D033O20 **Not stocked parts**)



Fig.5-5

When an undesirable colour appears at the area (a) in the figure above, attach the magnetic pieces on the opposite surface of the funnel with the magnetic pieces on the opposite surface facing outside. When an undesirable colour appears at the area (b) in the figure above, attach the magnetic pieces on the opposite surface of the funnel with the surface facing inside.

(CAUTION)

The magnetic piece will distort the raster and disturb the convergence system. Do not place magnetic piece closer than 50mm (2 inches) from the deflection yoke.
If an undesirable colour appears at the area shown ▨, move the magnetic piece counter-clockwise until the colour disappears.
If an undesirable colour appears at the area shown ▭, move the magnetic piece clockwise until the colour disappears.
After correction, degauss the set and then check the screen corners for discolouration. If exists, fine adjust the magnetic pieces for that corner.
Repeat degaussing and checking.

2. Focus Adjustment	(1) Supply a grey scale signal with window. (2) Observing around the vertical line, adjust FOCUS control for best overall focus. Refer to Focus (No.14) of electrical adjustment.
3. Static Convergence Adjustment	(1) Tune the receiver to a crosshatch signal. (2) Set the BRIGHTNESS and CONTRAST controls in centre positions. (3) Adjust the degree of angle between the tabs of the 4-pole magnet and the angular position green at the centre of the screen to converge the "B" and "R" beams on the screen. [Refer to Fig. 5-3(b)] (4) Adjust the degree of angle between the tabs of the 6-pole magnet and the angular position to congerge the "B" and "R" beams to the "G" beam at the centre of the screen. [Refer to Fig. 5-3(c)] (5) If necessary, repeat above steps. **Note 1:** * The 4-pole magnet moves "B" and "R" beams in equal distances but opposite directions. * The 6-pole magnet moves "B" and "R" beams in the same direction and distance. * The "G" beam is not movable by the 4-pole and 6-pole magnets. **Note 2:** Never perform focus adjustment after convergence adjustments. If focus is adjusted after the convergence adjustment, re-check the convergence.

4. Dynamic convergence Y_H adjustment (Deviation of the vertical axis in the horizontal direction.)

Input a crosshatch signal.

Observing top and bottom point on the screen, adjust the VR (Y_H), at the upper part of the deflection yoke, for best convergence.



Fig. 5-6(a)

Y_V adjustment (Deviation of the horizontal axis in the vertical direction.)

Adjust the VR(Y_V), in upper part of the deflection yoke, to converge horizontal lines at the top and bottom of the screen.



Fig. 5-6(b)

X_V adjustment (Deviation of horizontal axis in the vertical direction.)

Deviation should be corrected by adjusting the horizontal differential coil(core position).



Fig. 5-6(c)

If convergence is poor at corners, place the magnet at the aperture of the deflection yoke bobbin as shown in Fig. 5-7 so that PQH (Pin cushion quality H) and PQV(Pin cushion quality V) components shall be minimized.
To correct the A section of the screen in Fig. 5-7, stick a magnet to the position shown in Fig. 5-7 below.
(Part No. of the magnet : 461D017O10 **Not stocked parts**)



(Misconversion pattern)



Magnet mounting position
(Rear view of deflection yoke).

Fig. 5-7

5. Wedge position

After the position of the wedges has been determined, gently turn up the end of the wedge and strip the tape from the rear of the end to expose the adhesive material, then adhere to the picture tube cone. Apply silicone gum (Parts No. 859D106O20) between wedges and the picture tube cone. (Fig. 5-9)



Fig. 5-8



Fig. 5-9

Electrical Adjustment

Perform only the alignments required.
If proper equipment is not available, do not attempt an alignment.

■ Measuring equipment and Jigs

- Oscilloscope (Unless otherwise specified in particular, use 10:1 probes.)
- Signal generator
- Frequency counter
- Direct current voltmeter.
- Electrical tools

■ Test Signal

1) Monoscope signal
   When you have no monoscope signal source for adjustment, connect the unit to a VCR and play an alignment tape (Monoscope).

2) Colour bar signal
   In this manual, unless otherwise specified in particular, use colour bar signal in specifications below.



Split-Field Colour Bars (with 100% window)

LOCATION OF TESTPOINTS AND ADJUSTMENTS

PCB-SIGNAL (COMPONENT SIDE)



PCB-MBC-DEFL (COMPONENT SIDE)



PCB-SWIFTEXT (COMPONENT SIDE)



PCB-NICAM (COMPONENT SIDE)



PCB-YUV (COMPONENT SIDE)



PCB-DCF (COMPONENT SIDE)



TOP

PCB-PCC/DBF (COMPONENT SIDE) TOP



FRONT

PCB-CRT (COMPONENT SIDE) TOP



PCB-PIP (COMPONENT SIDE)



[Power Circuit] 1. B4 Voltage	**Adjustment purpose**	Setting supply voltage for each circuits.
	Symptom when incorrectly adjusted	Too bright or too dark picture. Too compressed or too expanded.

Measuring instrument	AC Voltmeter
Test point	TP 91
EXT trigger	---
Measurement range	---
Input signal	Video signal (Monoscope)
Input terminal	VIDEO IN terminal

1. Supply a video signal (Monoscope).
2. Observe the voltage at TP91.
3. Adjust VR951 so that the B4 voltage is 130V.

PCB-MBC-DEFL (COMPONENT SIDE)



[Chroma Circuit] 2. PAL Vector	**Adjustment purpose**	Setting each colour to the best result when receiving PAL signal.
	Symptom when incorrectly adjusted	Incorrect colour when receive PAL signal.

Measuring instrument	Oscilloscope
Test point	CH-1:TP61 CH-2:TP62
EXT trigger	---
Measurement range	DIV 10mV TIM X-Y mode
Input signal	Video signal (G card)
Input terminal	VIDEO IN terminal

1. Supply a video signal (G card).
2. Observe the waveform at TP61 and TP62. (CH-1 to TP61)
3. Set the oscilloscope to X-Y mode.
4. Adjust L603 so that outer double dots draw together.



5. Adjust VR601 so that the four pair of dots come nearer to the central bright point.

PCB-SIGNAL (COMPONENT SIDE)





3. SECAM Bell Filter

Adjustment purpose Setting carrier freguency for SECAM signal.

Symptom when incorrectly adjusted The colour is erratic.

Measuring instrument	Oscilloscope
Test point	TP63
EXT trigger	---
Measurement range	DIV 5mV TIM 20µs
Input signal	Video signal (SECAM Colour bar)
Input terminal	VIDEO IN terminal

1. Supply a video signal (SECAM Colour bar).
2. Observe the waveform at TP63.
3. Adjust L605 so that the amplitude of the magenta of the adjoining horizontal synchronization shall be nearly egual.

PCB-SIGNAL (COMPONENT SIDE)



4. SECAM Identification

Adjustment purpose Setting phase of chrominance subcarrier for SECAM signal.

Symptom when incorrectly adjusted Coloured monochrome when receive SECAM signal.

Measuring instrument	Oscilloscope
Test point	TP64
EXT trigger	---
Measurement range	DIV 0.1V TIM 10µs
Input signal	Video signal (SECAM Colour bar)
Input terminal	VIDEO IN terminal

* This adjustment must follow item 3 (SECAM Bell Filter).
1. Supply a video signal (SECAM Colour bar).
2. Observe the waveform at TP64.
3. Adjust L607 so that the DC level is maximum.

PCB-SIGNAL (COMPONENT SIDE)



5. SECAM Demodulator	**Adjustment purpose**	Setting each colour to the best result when receiving SECAM signal.
	Symptom when incorrectly adjusted	Incorrect colour when receive SECAM signal.

Measuring instrument	Oscilloscope
Test point	CH-1:TP61 CH-2:TP62
EXT trigger	---
Measurement range	DIV 10mV TIM X-Y mode
Input signal	Video signal (SECAM Colour bar)
Input terminal	VIDEO IN terminal

* This adjustment must follow item 4 (SECAM Identification).
1. Supply a video signal (SECAM Colour bar).
2. Observe the waveform at TP61 and TP62.(CH-1 to TP61)
3. Set the osilloscope to X-Y mode.
4. Adjust L601 and L602 so that the middle bright point corresponding to the white of vector and the bright point corresponding to the black shall be merged.





PCB-SIGNAL (COMPONENT SIDE)



6. Colour Output	**Adjustment purpose**	Setting colour level of video signal.
	Symptom when incorrectly adjusted	Too much or too little colour level.

Measuring instrument	Oscilloscope
Test point	TP65
EXT trigger	---
Measurement range	DIV 10mV TIM 10µs
Input signal	Video signal (SECAM Colour bar)
Input terminal	VIDEO IN terminal

* This adjustment must follow item 2 (PAL Vector), 13 (Cut off, white) and 15(Sub Cont).
1. Supply a video signal (SECAM Colour bar).
2. Press OPTIMUM button on the remote hand unit.
3. Observe the waveform at TP65.
4. Adjust VR602 so that the tops of the waveforms shall be flat.



PCB-SIGNAL (COMPONENT SIDE)



7. Sub Tint	**Adjustment purpose**	Setting each colour to the best result when receive NTSC signal.
	Symptom when incorrectly adjusted	Reddish or greenish picture when receive NTSC signal.

Measuring instrument	Oscilloscope
Test point	CH-1:TP61 CH-2:TP62
EXT trigger	---
Measurement range	DIV 10mV TIM X-Y mode
Input signal	Video signal (NTSC Colour bar)
Input terminal	VIDEO IN terminal

1. Supply a video signal (NTSC Colour bar) to AV1.
2. Press OPTIMUM button on the remote hand unit.
3. Observe the waveform at TP61 and TP62 (CH-1 to TP61).
4. Set the oscilloscope to X-Y mode.
5. Adjust VR603 so that the red dot is 103°.



PCB-SIGNAL (COMPONENT SIDE)



[Deflection Circuit] 8. Horizontal Centre	**Adjustment purpose**	Horizontal position of picture.
	Symptom when incorrectly adjusted	Picture too shifted to the left, or the right.

Measuring instrument	---
Test point	---
EXT trigger	---
Measurement range	---
Input signal	Video signal (Monoscope)
Input terminal	VIDEO IN terminal

1. Supply a video signal (Monoscope).
2. Adjust VR501 so that readings of left and right markers are the same.

PCB-SIGNAL (COMPONENT SIDE)



9. PCC	**Adjustment purpose**	Horizontal linearity of picture.
	Symptom when incorrectly adjusted	Horizontal distortion of picture.

Measuring instrument	---
Test point	---
EXT trigger	---
Measurement range	---
Input signal	Video signal (PAL Cross hatch)
Input terminal	VIDEO IN terminal

1. Supply a video signal (PAL Cross hatch).
2. Press OPTIMUM button on the remote hand unit.
3. Observing the second line (a), (b) from both ends on the screen. Adjust VR5003 and VR5002 for optimum EAST-WEST PCC.
4. Supply a video signal (NTSC Cross hatch).
5. Observing the second line (a), (b) from both ends on the screen. Adjust VR5002 for optimum EAST-WEST PCC phase.

Note: When the cross hatch signal change to the condition at PAL, confirm the signal is as good as the cross hatch signal at NTSC.





10. Horizontal Width	**Adjustment purpose**	Horizontal width of picture.
	Symptom when incorrectly adjusted	Too compressed or too expanded horizontal width of picture.

Measuring instrument	---
Test point	---
EXT trigger	---
Measurement range	---
Input signal	Video signal (Monoscope)
Input terminal	VIDEO IN terminal

1. Supply a video signal (Monoscope).
2. Press OPTIMUM button on the remote hand unit.
3. Adjust VR5001 so that the sum of left and right markers is 3.8–5.8 (eguivalent to 6–9% overscan).





11. Vertical Height, Vertical Linearity	**Adjustment purpose**	Vertical height and linearity of picture.
	Symptom when incorrectly adjusted	Too compressed or too expanded vertical height of picture. Vertical linearity of picture.

Measuring instrument	---
Test point	---
EXT trigger	---
Measurement range	---
Input signal	VIDEO signal (Monoscope)
Input terminal	VIDEO IN terminal

1. Supply a video signal (Monoscope).
2. Press OPTIMUM button on the remote hand unit.
3. Adjust VR452 for approx. 90% vertical size of raster.
4. Adjust VR451 for symmetry of vertical linearity.
5. Adjust VR452 so that the largerst circle is a complete round.



monoscope

PCB-MBC-DEFL (COMPONENT SIDE)



12. Vertical Centre Position	**Adjustment purpose**	Vertical position of picture.
	Symptom when incorrectly adjusted	Picture too shifted to the up, or the low.

Measuring instrument	---
Test point	---
EXT trigger	---
Measurement range	---
Input signal	Video signal (Monoscope)
Input terminal	VIDEO IN terminal

1. Supply a video signal (Monoscope).
2. Set S401 for optimum raster position.


monoscope

PCB-MBC-DEFL (COMPONENT SIDE)



[CRT Circuit]
13. Cut Off, White

Adjustment purpose Rate of electron beam shot from each electron gun of R, G and B.

Symptom when incorrectly adjusted Coloured monochrome, too dark or too bright picture.

Measuring instrument	Oscilloscope
Test point	Collector of Q651
EXT trigger	---
Measurement range	DIV 5V TIM 20μs
Input signal	---
Input terminal	---

1. Supply no signal to AV1.
2. Set AV1 mode.
3. Inhibit the blue background.
   ① Press "MENU" button on the remote hand unit three times.
   ② Push the button: 2 of the remote hand unit so that the frame which refer to figure is white.
   (Whenever push the button:2, the frame changes to white and blue alternately.)



   ③ Press "MENU" button.
4. Tilt S2001 to left or right.
5. Set VR651, VR652 and VR653 to fully counterclockwise position as seen from solder side.
6. Set VR654 and VR655 to the mechanical centre position.
7. Set VR202 to fully counterclockwise position as seen from solder side.
8. Set VR201 to the mechanical centre position.
9. Set SCREEN volume (on F.B.T.) to fully counterclockwise position.
10. Observe the waveform at the collector of Q651.(Use CT connector pin② for ground)
11. Adjust VR651 so that the DC voltage is 200V.



12. Observe the waveform at the collector of Q652.(Use CT connector pin② for ground)
13. Adjust VR652 so that the DC voltage is 200V.
14. Observe the waveform at the collector of Q653.(Use CT connector pin② for ground)
15. Adjust VR653 so that the DC voltage is 200V.
16. Short-circuit TP2 connector pin① and pin②.
17. Adjust SCREEN volume (on F.B.T.) to the point where one red, green or blue line becomes just visible.
18. Adjust two of VR651, VR652 and VR653 so that the horizontal line becomes white, e.g. if the original colour line was blue, adjust VR651 and VR653 to achieve a white line.
19. Return S2001 to the centre position.
20. Adjust VR2002 so that the horizontal line becomes bright.
21. Open the short circuit of TP2 connector pin① and pin②.
22. Supply a video signal (white raster).
23. Adjust VR654 and VR655 so that the entire screen is in pure white.
    If necessary, repeat step 1 to 23 above.

PCB-SIGNAL (COMPONENT SIDE)



PCB-MRC-DEFL (COMPONENT SIDE)



PCB-CRT (COMPONENT SIDE)



PCB-YUV (COMPONENT SIDE)



14. Focus	**Adjustment purpose** Sharpness of picture. **Symptom when incorrectly adjusted** Poor sharpness of picture.

Measuring instrument	---
Test point	---
EXT trigger	---
Measurement range	---
Input signal	Video signal (Grey Scale with Window)
Input terminal	VIDEO IN terminal

1. Supply a video signal (grey scale with window).
2. Observing around the vertical line.
3. Adjust FOCUS-2 volume (on F.B.T.) for best focus.
4. Observing around the horizontal line.
5. Adjust FOCUS-1 volume (on F.B.T) for best focus.
6. Repeat step 2 to 5 three times or more.





[Video Circuit] 15. Sub Cont	**Adjustment purpose** The best value of beam current. **Symptom when incorrectly adjusted** Too bright or too dark picture.

Measuring instrument	DC milliammeter
Test point	+lead:TP1 connector pin① −lead:TP1 connector pin④
EXT trigger	---
Measurement range	---
Input signal	Video signal (Colour bar)
Input terminal	VIDEO IN terminal

* This adjustment must follow item 13 (Cut Off, White).
1. Supply a video signal (Colour bar).
2. Set COLOUR control to minimum.
3. Observe the waveform at TP1 connector pin① and pin④. (Plus lead to TP connector pin①)
4. Adjust VR201 so that the beam current is 1500±20μA.





[Micro Computer Circuit]
16. Display Position

Adjustment purpose Charactor position on screen.

Symptom when incorrectly adjusted Charactors too shifted to the left, or the right.

Measuring instrument	---
Test point	---
EXT trigger	---
Measurement range	---
Input signal	Video signal (Centre cross)
Input terminal	VIDEO IN terminal

* This adjustment must follow item 8 (Horizontal Centre).
1. Supply a video signal (Centre cross).
2. Press OPTIMUM button on the remote hand unit.
3 Adjust VC701 so that the centre of the level bar is on the vertical line of the centre cross signal.



PCB-SIGNAL (COMPONENT SIDE)



[Teletext Circuit]
17. Teletext Free Run Frequency

Adjustment purpose The best detect condition of text signal from video signal.

Symptom when incorrectly adjusted Distorted text display.

Measuring instrument	Frequency Counter
Test point	TP1
EXT trigger	---
Measurement range	---
Input signal	---
Input terminal	---

* Preheat the set for five minutes or more.
1. Disconnect a antenna cable from RF IN terminal to display a snow noise on the screen.
2. Disconnect TE connector from PCB-SWIFTEXT.
3. Observe the frequency at TP1.
4. Adjust L7707 so that the frequency is 13.4±0.1MHz.

PCB-SWIFTEXT (COMPONENT SIDE)



[DCF Circuit] 18. CCD Insert Gain	**Adjustment purpose**	Setting input and output signal level of CCD circuit.
	Symptom when incorrectly adjusted	Too much or too little colour level.

Measuring instrument	Oscilloscope
Test point	TP1
EXT trigger	---
Measurement range	DIV 20mV TIM 10μs
Input signal	Video signal (Colour bar)
Input terminal	VIDEO IN terminal

1. Supply a video signal (Colour bar).
2. Observe the waveform at TP1.
3. Adjust VR6001 so that the amplitude of the video signal is 1.0Vp-p.
4. Observe the waveform at TP2.
5. Adjust VR6002 so that the amplitude of the video signal is 1.0Vp-p.



PCB-DCF (COMPONENT SIDE)



19. Vertical Correlation	**Adjustment purpose**	Reduced vertical dot disturbance.
	Symptom when incorrectly adjusted	Vertical dot disturbance is noticeable.

Measuring instrument	Oscilloscope
Test point	CH-1:TP3 CH-2:TP4
EXT trigger	---
Measurement range	DIV 10mV TIM 20μs
Input signal	Video signal (Colour bar)
Input terminal	VIDEO IN terminal

1. Supply a video signal (Colour bar).
2. Turn VR6003 fully counterclockwise as seen from component side.
3. Observe the waveform at TP3 and TP4 (CH-1 to TP3).
4. Set the oscilloscope's CH-2 to INVERT mode.
5. Set the oscilloscope to ADD mode.
6. Alternate adjustments in the following sequence:VR6003, VR6004 so that the chroma level is minimum.



7. Observe the waveform at TP3 and TP5 (CH-1 to TP3).
8. Set the oscilloscope's CH-2 to INVERT mode.
9. Set the oscilloscope to ADD mode.
10. Alternate adjustments in the following sequence: VR6005, VR6006 and L6001 so that the chroma level is minimum.

PCB-DCF (COMPONENT SIDE)



20. Y/C Separation

Adjustment purpose Separating video signal to Y signal and C-signal.

Symptom when incorrectly adjusted Dot disturbance is noticeable.

Measuring instrument	Oscilloscope
Test point	TP6
EXT trigger	---
Measurement range	DIV 20mV TIM 10µs
Input signal	Video signal (Colour bar)
Input terminal	VIDEO IN terminal

1. Supply a video signal (colour bar).
2. Observe the waveform at TP6.
3. Alternate adjustments in the following sequence : VR6007, VR6008 so that the chroma level is minimum.



PCB-DCF (COMPONENT SIDE)



[NICAM Circuit] 21. Carrier VCXO

Adjustment purpose Setting phase of NICAM signal.

Symptom when incorrectly adjusted Deteriorating detection sensitivity of NICAM signal.

Measuring instrument	Oscilloscope
Test point	CH-1:TP31 CH-2:TP32
EXT trigger	---
Measurement range	DIV 10mV TIM X-Y mode
Input signal	RF signal (NICAM stereo or dual sound)
Input terminal	RF IN terminal

1. Supply an RF signal (NICAM stereo or dual sound).
2. Observe the waveform at TP31 and TP32 (CH-1 to TP31).
3. Set the oscilloscope to X-Y mode.
4. Adjust VC3001 so that a square made by lining up four luminous point run parallel with a scale line of oscilloscope.



PCB-NICAM (COMPONENT SIDE)



22. Clock VCXO

Adjustment purpose Setting input clock pulse to NICAM circuit.

Symptom when incorrectly adjusted Disappear the sound.

Measuring instrument	DC Voltmeter
Test point	+lead : TP33 −lead : TP34
EXT trigger	---
Measurement range	---
Input signal	RF signal (NICAM stereo or dual sound)
Input terminal	RF IN terminal

1. Supply an RF signal (NICAM stereo or dual sound).
2. Observe the voltage at TP33 and TP34 (Plus lead to TP33).
3. Adjust VC3002 so that voltage difference is 0±30mV.

PCB-NICAM (COMPONENT SIDE)



[PIP Circuit]
23. 5MHz OSC

Adjustment purpose Setting input clock pulse to PIP circuit.

Symptom when incorrectly adjusted Too compressed or too expanded in sub picture.

Measuring instrument	---
Test point	---
EXT trigger	---
Measurement range	---
Input signal	Video signal (PAL G card)
Input terminal	VIDEO IN terminal

1. Supply a video signal (PAL G card).
2. Set the receiver to PIP mode.
3. Display G card signal on the main and sub picture, respectively.
4. Adjust VR7003 so that display widths of the sub picture are symmetrical with respect to the screen centre.

PCB-PIP (COMPONENT SIDE)



24. PAL Free Run Frequency	**Adjustment purpose**	Setting PAL free run frequency of sub picture to 4.43 MHz (chrominance subcarrier).
	Symptom when incorrectly adjusted	Coloured monochrome in sub picture when receive PAL signal.

Measuring instrument	---
Test point	---
EXT trigger	---
Measurement range	---
Input signal	RF signal (PAL G card)
Input terminal	RF IN terminal

1. Supply an RF signal (PAL G card).
2. Supply a video signal (PAL colour bar) to AV1.
3. Set the receiver to PIP mode.
4. Display PAL G card signal on the main picture.
5. Display PAL colour bar signal through AV1 on the sub picture.
6. Connect TP3 and Vcc (IC7008 pin⑱) through a resistor (220Ω).
7. Connect TP4 to ground.
8. Adjust VC7002 for almost colour synchronization.
9. Remove a resistor (220Ω) and ground used in step 6 and 7.

PCB-PIP (COMPONENT SIDE)



25. NTSC Free Run Frequency	**Adjustment purpose**	Setting NTSC free run frequency of sub picture to 3.58MHz (chrominance subcarrier).
	Symptom when incorrectly adjusted	Coloured monochrome in sub picture when receive NTSC signal.

Measuring instrument	---
Test point	---
EXT trigger	---
Measurement range	---
Input signal	RF signal (PAL G card)
Input terminal	RF IN terminal

1. Supply an RF signal (PAL G card).
2. Supply a video signal (NTSC colour bar) to AV1.
3. Set the receiver to PIP mode.
4. Display PAL G card signal on the main picture.
5. Display NTSC colour bar signal through AV1 on the sub picture.
6. Connect TP5 and Vcc (IC7008 pin⑨) through a resistor (220Ω).
7. Connect TP4 to ground.
8. Adjust VC7001 for almost colour synchronization.
9. Remove a resistor (220Ω) and ground used in step 6 and 7.

PCB-PIP (COMPONENT SIDE)



26. NTSC Sub Tint

Adjustment purpose Setting each colour to the best result for sub picture which receive NTSC signal.

Symptom when incorrectly adjusted Reddish or greenish picture in sub picture when receive NTSC signal.

Measuring instrument	Oscilloscope
Test point	CH-1 : TP7 CH-2 : TP6
EXT trigger	---
Measurement range	DIV 20mV TIM X-Y mode
Input signal	RF signal (PAL G card)
Input terminal	RF IN terminal

* This adjustment must follow item 25 (NTSC Free Run Frequency).
1. Supply an RF signal (PAL G card).
2. Supply a video signal (NTSC colour bar) to AV1.
3. Set the receiver to PIP mode.
4. Display PAL G card signal on the main picture.
5. Display NTSC colour bar signal through AV1 on the sub picture.
6. Observe the waveform at TP7 and TP6 (CH-1 to TP7).
7. Set the oscilloscope to X-Y mode.
8. Adjust VR7001 so that the red dot is 103°.



PCB-PIP (COMPONENT SIDE)



27. PAL Vector

Adjustment purpose Setting each colour to the best result for sub picture which receive PAL signal.

Symptom when incorrectly adjusted Incorrect colour in sub picture when receive PAL signal.

Measuring instrument	Oscilloscope
Test point	CH-1 : TP7 CH-2 : TP6
EXT trigger	---
Measurement range	VID 20mV TIM X-Y mode
Input signal	RF signal (PAL G card)
Input terminal	RF IN terminal

* This adjustment must follow item 24 (PAL Free Run Frequency).
1. Supply an RF signal (PAL G card).
2. Supply a video signal (PAL colour bar) to AV1.
3. Set the receiver to PIP mode.
4. Display PAL colour bar signal through AV1 on the main picture.
5. Display PAL G card signal on the sub picture.
6. Observe the waveform at TP7 and TP6 (CH-1 to TP7).
7. Set the oscilloscope to X-Y mode.
8. Adjust L7006 so that outward double dots draw together.



9. Adjust VR7002 so that the four pair of dots come nearer to the central bright point.

PCB-PIP (COMPONENT SIDE)





28. SECAM Bell Filter	**Adjustment purpose**	Setting carrier frequency in sub picture when receive SECAM signal.
	Symptom when incorrectly adjusted	The colour is erratic in sub picture when receive SECAM signal.

Measuring instrument	Oscilloscope (Probe 1 : 1)
Test point	TP9
EXT trigger	---
Measurement range	DIV 20mV TIM 20µs
Input signal	RF signal (SECAM colour bar)
Input terminal	RF IN terminal

1. Supply an RF signal (SECAM colour bar).
2. Supply a video signal (PAL colour bar) to AV1.
3. Set the receiver to PIP mode.
4. Dispaly SECAM colour bar signal on the main picture.
5. Display PAL colour bar signal through AV1 on the sub picture.
6. Connect TP8 and Vcc (IC 7008 pin ⑨) through a resistor (220Ω).
7. Observe the waveform at TP9.
8. Adjust L7001 so that the amplitude of the magenta of the adjoining horizontal synchronization shall be nearly equal.
9. Remove a resistor (220Ω).



PCB-PIP (COMPONENT SIDE)



29. SECAM Identification	**Adjustment purpose**	Setting phase of chrominance subcarrier in sub picture when receive SECAM signal.
	Symptom when incorrectly adjusted	Coloured monochrome in sub picture when receive SECAM signal.

Measuring instrument	Oscilloscope
Test point	TP10
EXT trigger	---
Measurement range	DIV 0.2V TIM 0.5ms
Input signal	RF signal (SECAM colour bar)
Input terminal	RF IN terminal

* This adjustment must follow item28 (PIP SECAM Bell Filter).
1. Supply an RF signal (SECAM colour bar).
2. Supply a video signal (PAL colour bar) to AV1.
3. Set the receiver to PIP mode.
4. Display PAL colour bar signal through AV1 on the main picture.
5. Display SECAM colour bar signal on the sub picture.
6. Connect TP10 and Vcc (IC7008 pin⑨) through a resistor (10MΩ).
7. Connect TP8 and Vcc (IC7008 pin⑨) through a resistor (220Ω).
8. Observe the waveform at TP10.
9. Adjust L7002 so that the DC level is maximum.
10. Remove two resistors.

PCB-PIP (COMPONENT SIDE)



30. SECAM Demodulator	**Adjustment purpose**	Setting each colour to the best result when receive SECAM signal.
	Symptom when incorrectly adjusted	Incorrect colour in sub picture when receive SECAM signal.

Measuring instrument	Oscilloscope
Test point	CH-1 : TP7 CH-2 : TP6
EXT trigger	---
Measurement range	DIV 20mV TIM X-Y mode
Input signal	RF signal (SECAM colour bar)
Input terminal	RF IN terminal

* This adjustment must item29 (PIP SECAM Identification).
1. Supply an RF signal (SECAM colour bar).
2. Supply a video signal (PAL colour bar) to AV1.
3. Set the receiver to PIP mode.
4. Display PAL colour bar signal through AV1 on the main picture.
5. Dispaly SECAM colour bar signal on the sub picture.
6. Connect TP10 and Vcc (IC 7008 pin⑲) through a resistor (10MΩ).
7. Observe the waveform at TP7 and TP6 (CH-1 to TP7).
8. Set the oscilloscope to X-Y mode.
9. Adjust L7003 and L7004 so that the middle bright point corresponding to the black shall be merged.
10. Remove a resistor (10MΩ).

PCB-PIP (COMPONENT SIDE)





PARTS LIST

MODEL : CT – 37C2EDT

In order to expedite delivery of replacement part orders.
Specify : 1. Model number/Serial number
2. Part number and Description
3. Quantity
Unless full information is supplied, delay in execution of orders will result.

⚠ : Critical components

MARK	B	C	D	F	G	J	K
TOLERANCE (%)	± 0.1	± 0.25	± 0.5	± 1	± 2	± 5	± 10

MARK	M	N	V	X	Z	P	Q
TOLERANCE (%)	± 20	± 30	+ 10 − 10	+ 40 − 20	+ 80 − 20	+ 100 − 0	+ 30 − 10

MARK	B	C	D	F	G
TOLERANCE (pF)	± 0.1	± 0.25	± 0.5	± 1	± 2

SYMBOL NO.	PARTS NO.	PARTS NAME	DESCRIPTION
		TUBES	
⚠V 271	255B005001	CRT ASSY	M89KCW11X
		INTEGRATED CIRCUITS	
IC101	272P486010	IC	μPC78M09H
IC201	272P487010	IC	TA8659AN
IC202	272P420010	IC	TEA5114A
IC203	272P420010	IC	TEA5114A
IC204	272P420010	IC	TEA5114A
IC205	263P551030	IC	MC14551BCP
IC207	263P053020	IC	TC4053BP
IC2A1	272P138010	IC	LA7952
IC2A2	266P279010	IC	M51321P
IC2A3	266P064010	IC	M51320P
IC2P2	263P053020	IC	TC4053BP
IC2P3	263P053020	IC	TC4053BP
IC2001	272P055010	IC	AN5860
IC2002	272P181010	IC	CX20125
IC301	263P053020	IC	TC4053BP
IC302	272P145010	IC	STK4132MK2
IC3A1	272P139010	IC	LA7953
IC3A2	272P039010	IC	LC7523
IC3A3	272P396010	IC	BX7601A
IC3A4	272P396010	IC	BX7601A
IC3A5	263P053020	IC	TC4053BP
IC3001	266P982010	IC	AN608P
IC3002	266P982010	IC	AN608P
IC3003	272P283010	IC	TA8662N
IC3004	263P636010	IC	TC6011N
IC3005	263P822020	IC	HM6264ALSP10/12
IC3006	272P284010	IC	TD6710AN
IC3007	267P036020	IC	AFL87F14000A11
IC3008	267P036020	IC	AFL87F14000A11
IC3009	266P546010	IC	RC4558P
IC3014	272P200020	IC	M5201L
IC3015	272P200020	IC	M5201L
IC451	272P239040	IC	LA7838
IC5001	272P406010	IC	TEA2031A
IC601	272P170010	IC	TDA4565 CTI
IC6001	272P292010	IC	CXL1009P
IC6002	267P032020	IC	BX6387
IC6003	272P292010	IC	CXL1009P
IC6004	267P035020	IC	BPF2(B080-2)
IC6005	267P027020	IC	BPF(B074-2)
IC6006	267P035020	IC	BPF2(B080-2)
IC6007	267P032020	IC	BX6387
IC6008	266P982010	IC	AN608P
IC6009	267P032010	IC	BX6386
IC6010	272P262010	IC	CX22013
IC6011	267P028020	IC	SUB(B075-2)
IC6012	263P053020	IC	TC4053BP
IC6013	266P923020	IC	NJM78L09A
IC701	263P155020	IC	μPD75116CW-168
IC702	263P156010	IC	M50554-185SP

SYMBOL NO.	PARTS NO.	PARTS NAME	DESCRIPTION
IC705	263P872030	IC	MN1280-M
IC706	263P869010	IC	μPD6326C
IC707	263P052050	IC	HEF4052BP
IC709	266P727040	IC	μPC339C/LM339N
IC711	266P727040	IC	μPC339C/LM339N
IC712	263P053020	IC	TC4053BP
IC7001	263P795010	IC	M50541FP
IC7002	263P509010	IC	MM74HCU04N/TC74H
IC7003	272P246010	IC	SN74124N
IC7004	266P934070	IC	μPC7805H
IC7005	272P249010	IC	M52684AP
IC7006	272P249010	IC	M52684AP
IC7007	266P636010	IC	LA7950
IC7008	272P171010	IC	TDA4556 MSD
IC7009	272P251010	IC	M52686P
IC7010	263P794040	IC	M5M4C500AL-5
IC7011	272P444010	IC	M526282P
IC7401	263P346010	IC	M50253P
IC7701	272P861010	IC	SAA5191
IC7702	274P179010	IC	SAA9042P
IC7703	274P180010	IC	TC514256AP-80
IC7704	274P178010	IC	PC883C528
IC7705	263P434020	IC	X24C04P
IC901	272P514010	IC	TEA2261
IC950	272P412010	IC	TEA5170
IC951	267P076030	IC	S1-3050C
IC952	266P922010	IC	μPC78M05H
IC953	272P240010	IC	M5237L
IC954	266P910020	IC	μPC574J-K
IC955	272P240010	IC	M5237L
ICSA1	272P570010	IC	M51848P
	930C475001	IC ASSY	IC703(263P683010)
	930C475002	IC ASSY	IC704(263P683010)
		TRANSISTORS	
Q 101	260P543050	TRANSISTOR	JC501-Q
Q 201	260P654030	TRANSISTOR	2SC2058S-Q
Q 202	260P543050	TRANSISTOR	JC501-Q
Q 203	260P543050	TRANSISTOR	JC501-Q
Q 204	260P543050	TRANSISTOR	JC501-Q
Q 207	260P543050	TRANSISTOR	JC501-Q
Q 208	260P544030	TRANSISTOR	JA101-Q
Q 209	260P543050	TRANSISTOR	JC501-Q
Q 210	260P544030	TRANSISTOR	JA101-Q
Q 211	260P543050	TRANSISTOR	JC501-Q
Q 213	260P543050	TRANSISTOR	JC501-Q
Q 214	260P544030	TRANSISTOR	JA101-Q
Q 215	260P544030	TRANSISTOR	JA101-Q
Q 216	260P543050	TRANSISTOR	JC501-Q
Q 217	260P544030	TRANSISTOR	JA101-Q
Q 218	260P544030	TRANSISTOR	JA101-Q
Q 219	260P544030	TRANSISTOR	JA101-Q
Q 220	260P544030	TRANSISTOR	JA101-Q
Q 221	260P544030	TRANSISTOR	JA101-Q
Q 222	260P654030	TRANSISTOR	2SC2058S-Q

SYMBOL NO.	PARTS NO.	PARTS NAME	DESCRIPTION
Q 223	260P544030	TRANSISTOR	JA101-Q
Q 224	260P544030	TRANSISTOR	JA101-Q
Q 2A1	260P543050	TRANSISTOR	JC501-Q
Q 2A2	260P543050	TRANSISTOR	JC501-Q
Q 2A3	260P554030	TRANSISTOR	2SC2058S-Q
Q 2A4	260P543050	TRANSISTOR	JC501-Q
Q 2A5	260P543050	TRANSISTOR	JC501-Q
Q 2A6	260P543050	TRANSISTOR	JC501-Q
Q 2A7	260P543050	TRANSISTOR	JC501-Q
Q 2A8	260P543050	TRANSISTOR	JC501-Q
Q 2A9	260P543050	TRANSISTOR	JC501-Q
Q 2B0	260P544030	TRANSISTOR	JA101-Q
Q 2B2	260P543050	TRANSISTOR	JC501-Q
Q 2B3	260P654030	TRANSISTOR	2SC2058S-Q
Q 2B4	260P543050	TRANSISTOR	JC501-Q
Q 2B5	260P543050	TRANSISTOR	JC501-Q
Q 2B6	260P543050	TRANSISTOR	JC501-Q
Q 2B7	260P544030	TRANSISTOR	JA101-Q
Q 2B8	260P544030	TRANSISTOR	JA101-Q
Q 2B9	260P543050	TRANSISTOR	JC501-Q
Q 2C0	260P543050	TRANSISTOR	JC501-Q
Q 2001	260P544030	TRANSISTOR	JA101-Q
Q 2002	260P543050	TRANSISTOR	JC501-Q
Q 2003	260P543050	TRANSISTOR	JC501-Q
Q 2004	260P543050	TRANSISTOR	JC501-Q
Q 2005	260P543050	TRANSISTOR	JC501-Q
Q 2006	260P543050	TRANSISTOR	JC501-Q
Q 2007	260P543050	TRANSISTOR	JC501-Q
Q 2008	260P543050	TRANSISTOR	JC501-Q
Q 2009	260P543050	TRANSISTOR	JC501-Q
Q 2010	260P543050	TRANSISTOR	JC501-Q
Q 301	260P543050	TRANSISTOR	JC501-Q
Q 302	260P543050	TRANSISTOR	JC501-Q
Q 303	260P544030	TRANSISTOR	JA101-Q
Q 304	260P543050	TRANSISTOR	JC501-Q
Q 305	260P543050	TRANSISTOR	JC501-Q
Q 3A1	260P543050	TRANSISTOR	JC501-Q
Q 3A2	260P387030	TRANSISTOR	2SC2236-Y
Q 3A3	260P544030	TRANSISTOR	JA101-Q
Q 3A4	260P543050	TRANSISTOR	JC501-Q
Q 3A5	260P543050	TRANSISTOR	JC501-Q
Q 3001	260P543050	TRANSISTOR	JC501-Q
Q 3002	260P416030	TRANSISTOR	2SC2274-F
Q 3003	260P543050	TRANSISTOR	JC501-Q
Q 3004	260P543050	TRANSISTOR	JC501-Q
Q 3006	260P543050	TRANSISTOR	JC501-Q
Q 3007	260P543050	TRANSISTOR	JC501-Q
Q 3008	260P543050	TRANSISTOR	JC501-Q
Q 3201	260P543050	TRANSISTOR	JC501-Q
Q 3202	260P543050	TRANSISTOR	JC501-Q
Q 451	260P543050	TRANSISTOR	JC501-Q
Q 501	260P543050	TRANSISTOR	JC501-Q
Q 502	260P543050	TRANSISTOR	JC501-Q
Q 503	260P544030	TRANSISTOR	JA101-Q
Q 504	260P543050	TRANSISTOR	JC501-Q

SYMBOL NO.	PARTS NO.	PARTS NAME	DESCRIPTION
Q 505	260P543050	TRANSISTOR	JC501-Q
Q 506	260P544030	TRANSISTOR	JA101-Q
Q 507	260P543050	TRANSISTOR	JC501-Q
Q 508	260P543050	TRANSISTOR	JC501-Q
Q 551	260P422010	TRANSISTOR	2SC2482
Q 552	260P608010	TRANSISTOR	2SD1879
Q 5006	260P543050	TRANSISTOR	JC501-Q
Q 5501	260P543050	TRANSISTOR	JC501-Q
Q 5502	260P543050	TRANSISTOR	JC501-Q
Q 5503	260P641010	TRANSISTOR	2SC4634/2SC4450
Q 5504	260P543030	TRANSISTOR	JC501-R
Q 601	260P543050	TRANSISTOR	JC501-Q
Q 602	260P543050	TRANSISTOR	JC501-Q
Q 603	260P543050	TRANSISTOR	JC501-Q
Q 604	260P543050	TRANSISTOR	JC501-Q
Q 605	260P543050	TRANSISTOR	JC501-Q
Q 606	260P543050	TRANSISTOR	JC501-Q
Q 607	260P543050	TRANSISTOR	JC501-Q
Q 608	260P543050	TRANSISTOR	JC501-Q
Q 651	260P425040	TRANSISTOR	2SC2688-M, N
Q 652	260P425040	TRANSISTOR	2SC2688-M, N
Q 653	260P425040	TRANSISTOR	2SC2688-M, N
Q 654	260P544030	TRANSISTOR	JA101-Q
Q 655	260P654030	TRANSISTOR	2SC2058S-Q
Q 656	260P654030	TRANSISTOR	2SC2058S-Q
Q 657	260P654030	TRANSISTOR	2SC2058S-Q
Q 658	260P422010	TRANSISTOR	2SC2482
Q 659	260P422010	TRANSISTOR	2SC2482
Q 660	260P422010	TRANSISTOR	2SC2482
Q 6A1	260P543050	TRANSISTOR	JC501-Q
Q 6A3	260P544030	TRANSISTOR	JA101-Q
Q 6001	260P543050	TRANSISTOR	JC501-Q
Q 6002	260P543050	TRANSISTOR	JC501-Q
Q 6003	260P544030	TRANSISTOR	JA101-Q
Q 6004	260P654030	TRANSISTOR	2SC2058S-Q
Q 6005	260P544030	TRANSISTOR	JA101-Q
Q 6006	260P544030	TRANSISTOR	JA101-Q
Q 6007	260P543050	TRANSISTOR	JC501-Q
Q 6008	260P543050	TRANSISTOR	JC501-Q
Q 6009	260P543050	TRANSISTOR	JC501-Q
Q 6010	260P543050	TRANSISTOR	JC501-Q
Q 6011	260P544030	TRANSISTOR	JA101-Q
Q 705	260P543050	TRANSISTOR	JC501-Q
Q 706	260P543050	TRANSISTOR	JC501-Q
Q 713	260P543050	TRANSISTOR	JC501-Q
Q 714	260P544030	TRANSISTOR	JA101-Q
Q 715	260P544030	TRANSISTOR	JA101-Q
Q 716	260P544030	TRANSISTOR	JA101-Q
Q 718	260P543050	TRANSISTOR	JC501-Q
Q 719	260P543050	TRANSISTOR	JC501-Q
Q 7P1	260P543050	TRANSISTOR	JC501-Q
Q 7P2	260P544030	TRANSISTOR	JA101-Q
Q 7Y1	260P543050	TRANSISTOR	JC501-Q
Q 7Y2	260P543050	TRANSISTOR	JC501-Q
Q 7001	260P543050	TRANSISTOR	JC501-Q

SYMBOL NO.	PARTS NO.	PARTS NAME	DESCRIPTION
Q 7002	260P543050	TRANSISTOR	JC501-Q
Q 7003	260P543050	TRANSISTOR	JC501-Q
Q 7004	260P543050	TRANSISTOR	JC501-Q
Q 7005	260P543050	TRANSISTOR	JC501-Q
Q 7006	260P543050	TRANSISTOR	JC501-Q
Q 7007	260P543050	TRANSISTOR	JC501-Q
Q 7008	260P543050	TRANSISTOR	JC501-Q
Q 7009	260P544030	TRANSISTOR	JA101-Q
Q 7010	260P544030	TRANSISTOR	JA101-Q
Q 7011	260P544030	TRANSISTOR	JA101-Q
Q 7012	260P544030	TRANSISTOR	JA101-Q
Q 7013	260P544030	TRANSISTOR	JA101-Q
Q 7014	260P544030	TRANSISTOR	JA101-Q
Q 7015	260P544030	TRANSISTOR	JA101-Q
Q 7017	260P544030	TRANSISTOR	JA101-Q
Q 7018	260P544030	TRANSISTOR	JA101-Q
Q 7019	260P582010	TRANSISTOR	2SK656
Q 7020	260P543050	TRANSISTOR	JC501-Q
Q 7021	260P543050	TRANSISTOR	JC501-Q
Q 7022	260P544030	TRANSISTOR	JA101-Q
Q 7701	260P544030	TRANSISTOR	JA101-Q
Q 7702	260P543050	TRANSISTOR	JC501-Q
Q 7703	260P543050	TRANSISTOR	JC501-Q
Q 7704	260P543050	TRANSISTOR	JC501-Q
Q 7705	260P543050	TRANSISTOR	JC501-Q
Q 7706	260P654030	TRANSISTOR	2SC2058S-Q
Q 7707	260P654030	TRANSISTOR	2SC2058S-Q
Q 7708	260P654030	TRANSISTOR	2SC2058S-Q
Q 7709	260P543050	TRANSISTOR	JC501-Q
Q 7710	260P543050	TRANSISTOR	JC501-Q
Q 7711	260P543050	TRANSISTOR	JC501-Q
Q 7712	260P543050	TRANSISTOR	JC501-Q
Q 7713	260P544030	TRANSISTOR	JA101-Q
Q 8001	260P573020	TRANSISTOR	2SB940A-P
Q 8002	260P574020	TRANSISTOR	2SD1264A-P
Q 8003	260P543050	TRANSISTOR	JC501-Q
Q 8004	260P544030	TRANSISTOR	JA101-Q
Q 8005	260P543050	TRANSISTOR	JC501-Q
Q 8006	260P543050	TRANSISTOR	JC501-Q
Q 8007	260P543050	TRANSISTOR	JC501-Q
Q 8008	260P543050	TRANSISTOR	JC501-Q
Q 8009	260P543050	TRANSISTOR	JC501-Q
Q 8010	260P543050	TRANSISTOR	JC501-Q
Q 8012	260P635010	TRANSISTOR	2SC3055F/2SC3065G
Q 901	260P683010	TRANSISTOR	2SD1887
Q 902	260P543050	TRANSISTOR	JC501-Q
Q 950	260P255040	TRANSISTOR	2SA950-Y
Q 951	260P543050	TRANSISTOR	JC501-Q
Q 952	260P668020	TRANSISTOR	
Q 953	260P668010	TRANSISTOR	2SB1135-R, S
Q 954	260P543050	TRANSISTOR	JC501-Q

DIODES

SYMBOL NO.	PARTS NO.	PARTS NAME	DESCRIPTION
D 101	264P370010	DIODE	1N4148
D 102	264P370010	DIODE	1N4148
D 103	264P370010	DIODE	1N4148
D 104	264P370010	DIODE	1N4148
D 203	264P370010	DIODE	1N4148
D 204	264P370010	DIODE	1N4148
D 205	264P370010	DIODE	1N4148
D 206	264P370010	DIODE	1N4148
D 207	264P370010	DIODE	1N4148
D 2A1	264P488020	DIODE	RD13ED1
D 2A2	264P488020	DIODE	RD13ED1
D 2A3	264P483080	DIODE	RD5.1FB2
D 2A6	264P488020	DIODE	RD13ED1
D 2A7	264P488020	DIODE	RD13ED1
D 2A8	264P483080	DIODE	RD5.1FB2
D 2A9	264P483080	DIODE	RD5.1FB2
D 2B0	264P483080	DIODE	RD5.1FB2
D 2B1	264P483080	DIODE	RD5.1FB2
D 2B2	264P501020	DIODE	HZ2BLL
D 2B3	264P370010	DIODE	1N4148
D 2B4	264P370010	DIODE	1N4148
D 2B5	264P488020	DIODE	RD13ED1
D 2B6	264P488020	DIODE	RD13ED1
D 2P1	264P488020	DIODE	RD13ED1
D 2P2	264P488020	DIODE	RD13ED1
D 2001	264P370010	DIODE	1N4148
D 2002	264P370010	DIODE	1N4148
D 2003	264P370010	DIODE	1N4148
D 2004	264P370010	DIODE	1N4148
D 2005	264P370010	DIODE	1N4148
D 2006	264P370010	DIODE	1N4148
D 301	264P370010	DIODE	1N4148
D 302	264P370010	DIODE	1N4148
D 303	264P374020	DIODE	1N4003ID
D 304	264P370010	DIODE	1N4148
D 3A1	264P463080	DIODE	EQA02-09C/RD9.1EB3
D 3A2	264P465080	DIODE	EQA02-13A/RD13EB3
D 3A3	264P370010	DIODE	1N4148
D 3A5	264P483080	DIODE	RD5.1FB2
D 3B1	264P488060	DIODE	RD15FB1
D 3001	264P464050	DIODE	EQA02-10C
D 3201	264P370010	DIODE	1N4148
D 3202	264P370010	DIODE	1N4148
D 3203	264P370010	DIODE	1N4148
D 3204	264P370010	DIODE	1N4148
D 3205	264P370010	DIODE	1N4148
D 401	264P485070	DIODE	RD7.5FB3
D 451	264P374020	DIODE	1N4003ID
D 453	264P374020	DIODE	1N4003ID
D 454	264P374020	DIODE	1N4003ID
D 502	264P463080	DIODE	EQA02-09C/RD9.1EB3
D 551	264P375010	DIODE	BY228
D 552	264P378010	DIODE	BYW96E
D 553	264P371010	DIODE	BYD33G
D 554	264P295030	DIODE	ES 1F
D 555	264P371010	DIODE	BYD33G

SYMBOL NO.	PARTS NO.	PARTS NAME	DESCRIPTION
D 556	264P371010	DIODE	BYD33G
D 557	264P471070	DIODE	EQA02-35C/RD39EB2
D 558	264P370010	DIODE	1N4148
D 559	264P370010	DIODE	1N4148
D 5001	264P370010	DIODE	1N4148
D 5002	264P370010	DIODE	1N4148
D 5005	264P370010	DIODE	1N4148
D 5006	264P370010	DIODE	1N4148
D 5501	264P370010	DIODE	1N4148
D 5502	264P528010	DIODE	RP 1H
D 602	264P370010	DIODE	1N4148
D 603	264P370010	DIODE	1N4148
D 604	264P370010	DIODE	1N4148
D 605	264P370010	DIODE	1N4148
D 651	264P370010	DIODE	1N4148
D 652	264P370010	DIODE	1N4148
D 653	264P370010	DIODE	1N4148
D 654	264P371010	DIODE	BYD33G
D 655	264P371010	DIODE	BYD33G
D 657	264P370010	DIODE	1N4148
D 658	264P370010	DIODE	1N4148
D 6A1	264P483080	DIODE	RD5.1FB2
D 6A2	264P483080	DIODE	RD5.1FB2
D 705	264P486020	DIODE	RD8.2FB3
D 706	264P370010	DIODE	1N4148
D 707	264P370010	DIODE	1N4148
D 708	264P370010	DIODE	1N4148
D 709	264P370010	DIODE	1N4148
D 711	264P376010	DIODE	1N4148
D 7P2	264P370010	DIODE	1N4148
D 7X1	264P393010	LIGHT EMITTING DIODE	SLC-26VR5F
D 7X2	264P393030	LIGHT EMITTING DIODE	SLC-26DU5F
D 7Y3	264P483080	DIODE	RD5.1FB2
D 7Y4	264P483080	DIODE	RD5.1FB2
D 7001	264P370010	DIODE	1N4148
D 7002	264P370010	DIODE	1N4148
D 7003	264P370010	DIODE	1N4148
D 7004	264P370010	DIODE	1N4148
D 7005	264P370010	DIODE	1N4148
D 7006	264P370010	DIODE	1N4148
D 7007	264P370010	DIODE	1N4148
D 8001	264P370010	DIODE	1N4148
D 8002	264P370010	DIODE	1N4148
D 8003	264P374020	DIODE	IN4003ID
D 8004	264P374020	DIODE	IN4003ID
D 901	264P376010	DIODE	BYW56
D 902	264P376010	DIODE	BYW56
D 903	264P376010	DIODE	BYW56
D 904	264P376010	DIODE	BYW56
D 905	264P371010	DIODE	BYD33G
D 906	264P372010	DIODE	BYV96E
D 907	264P481060	DIODE	RD3.0FB2
D 909	264P481060	DIODE	RD3.0FB2
D 910	264P370010	DIODE	1N4148
D 911	264P484020	DIODE	RD5.6FB1

SYMBOL NO.	PARTS NO.	PARTS NAME	DESCRIPTION
D 912	264P456020	DIODE	RD2.0EB1
D 914	264P458030	DIODE	RD3.6EB2
D 915	264P484020	DIODE	RD5.6FB1
D 950	264P358070	DIODE	RU 4AM
D 951	264P377010	DIODE	BYW95B
D 952	264P566010	DIODE	FMP-G12S
D 953	264P377010	DIODE	BYW95B
D 956	264P377010	DIODE	BYW95B
D 957	264P377010	DIODE	BYW95B
D 958	264P370010	DIODE	1N4148
D 959	264P370010	DIODE	1N4148
D 960	264P370010	DIODE	1N4148
D 961	264P370010	DIODE	1N4148
D 9A1	264P374020	DIODE	IN4003ID
D 9A2	264P370010	DIODE	1N4148
		OTHER SEMICONDUCTORS	
RP901	265P047050	POSITIVE THERMISTOR	PTH BG 180M290
		FILTERS	
CF3001	299P144010	CERAMIC RESONATOR	CSA1B.93MX040
CF501	299P051030	CERAMIC RESONATOR	CSB503F15
CF7001	299P051050	CERAMIC RESONATOR	CSB500F9
CF7002	299P051050	CERAMIC RESONATOR	CSB500F9
CF7003	296P090020	CERAMIC RESONATOR	
LC3001	409P453020	BAND PASS FILTER	20800DAF
LF6001	409P478010	LOW PASS FILTER	
LF6002	409P478010	LOW PASS FILTER	
LF6003	409P458020	BAND PASS FILTER	
LF7001	409P217010	LOW PASS FILTER	
		DELAY LINES	
DF6001	409P432010	DELAY EQUALIZER	
DF6002	409P458020	DELAY EQUALIZER	
DF6003	409P498010	DELAY EQUALIZER	
DL601	337P027020	DELAY LINE	DL-711
DL6001	337P130010	DELAY LINE	
DL7001	337P027020	DELAY LINE	DL-711
		COILS	
	409B058020	CANCEL COIL	
⚠	409B070030	DEGAUSSING COIL	
⚠	330P157020	DEFLECTION YOKE COIL	
L 101	321C031040	RF COIL	10 μ H-K
L 102	321C031040	RF COIL	10 μ H-K
L 201	325C111030	PEAKING COIL	10 μ H-K
L 2A1	325C111030	PEAKING COIL	10 μ H-K
L 2001	325C101060	PEAKING COIL	18 μ H-K
L 3A1	325C121030	PEAKING COIL	10 μ H-K
L 3A2	325C121030	PEAKING COIL	10 μ H-K
L 3A3	325C121030	PEAKING COIL	10 μ H-K
L 3A4	325C121030	PEAKING COIL	10 μ H-K
L 3A5	325C121030	PEAKING COIL	10 μ H-K
L 3A6	325C121030	PEAKING COIL	10 μ H-K

SYMBOL NO.	PARTS NO.	PARTS NAME	DESCRIPTION
L 3A7	325C121030	PEAKING COIL	10 μH-K
L 3A8	325C121030	PEAKING COIL	10 μH-K
L 3A9	325C110070	PEAKING COIL	3.3 μH-K
L 3B0	325C110070	PEAKING COIL	3.3 μH-K
L 3B1	411P001070	FERRITE LEAD	BF60T
L 3B2	411P001070	FERRITE LEAD	BF60T
L 3B3	321C031040	RF COIL	10 μH-K
L 3Y1	325C111030	PEAKING COIL	10 μH-K
L 3Y2	325C111030	PEAKING COIL	10 μH-K
L 3Y3	325C111030	PEAKING COIL	10 μH-K
L 3001	325C108060	PEAKING COIL	820 μH-J
L 3002	325C108060	PEAKING COIL	820 μH-J
L 551	321C030010	RF COIL	1.0 μH-K
L 552	411D009020	FERRITE CORE FILTER	
L 553	409P407010	BRIDGE COIL	
L 554	409P408010	PCC COIL	
L 555	333P018020	H-LIN. COIL	
L 556	409P006080	FILTER COIL	6800 μH-J
L 557	409P556010	FILTER COIL	
L 558	321C031040	RF COIL	10 μH-K
L 5001	325C121030	PEAKING COIL	10 μH-K
L 601	349P187010	DEMODULATOR COIL	
L 602	349P187010	DEMODULATOR COIL	
L 603	349P188010	DL OUT COIL	
L 604	325C106050	PEAKING COIL	15 μH-J
L 605	349P172010	BELL FILTER	
L 606	325C106070	PEAKING COIL	22 μH-J
L 607	349P174010	IDENT COIL	MSD-SECAM
L 608	325C107090	PEAKING COIL	220 μH-J
L 609	325C107030	PEAKING COIL	68 μH-J
L 610	325C107010	PEAKING COIL	47 μH-J
L 611	325C122050	PEAKING COIL	100 μH-K
L 612	325C122050	PEAKING COIL	100 μH-K
L 613	321C031040	RF COIL	10 μH-K
L 654	321C031020	RF COIL	6.8 μH-K
L 6001	349P144020	DL MATCH COIL	14 μH
L 6002	325C102050	PEAKING COIL	100 μH-K
L 6003	325C162050	PEAKING COIL	100 μH-K
L 6004	411P011010	BEAD FERRITE	ZBF503S-P
L 6005	325C162050	PEAKING COIL	100 μH-K
L 6006	409P402030	EMI FILTER	DSS306-55FZ103N100
L 6007	409P402030	EMI FILTER	DSS306-55FZ103N100
L 6008	325C162050	PEAKING COIL	100 μH-K
L 6009	325C162050	PEAKING COIL	100 μH-K
L 6010	325C166020	PEAKING COIL	8.2 μH-J
L 6011	325C166010	PEAKING COIL	6.8 μH-J
L 6012	321C031040	RF COIL	10 μH-K
L 6014	325C121050	PEAKING COIL	15 μH-K
L 701	325C106050	PEAKING COIL	15 μH-J
L 7Y1	325C111030	PEAKING COIL	10 μH-K
L 7Y2	325C111030	PEAKING COIL	10 μH-K
L 7001	349P172010	BELL FILTER	
L 7002	349P174010	IDENT COIL	MSD-SECAM
L 7003	349P173010	DEMODULATOR COIL	
L 7004	349P173010	DEMODULATOR COIL	

SYMBOL NO.	PARTS NO.	PARTS NAME	DESCRIPTION
L 7005	325C106040	PEAKING COIL	12 μH-J
L 7006	349P185010	DL OUT COIL	
L 7007	321C031040	RF COIL	10 μH-K
L 7008	321C030070	RF COIL	3.3 μH-K
L 7009	325C120010	PEAKING COIL	1.0 μH-M
L 7010	325C120010	PEAKING COIL	1.0 μH-M
L 7011	325C120010	PEAKING COIL	1.0 μH-M
L 7014	325C120010	PEAKING COIL	1.0 μH-M
L 7015	325C120010	PEAKING COIL	1.0 μH-M
L 7016	325C120010	PEAKING COIL	1.0 μH-M
L 7017	411P013020	FERRITE LEAD	
L 7018	411P013020	FERRITE LEAD	
L 7401	325C106030	PEAKING COIL	10 μH-J
L 7402	321C031040	RF COIL	10 μH-K
L 7701	321C031040	RF COIL	10 μH-K
L 7702	325C121050	PEAKING COIL	15 μH-K
L 7703	321C030010	RF COIL	1.0 μH-K
L 7706	321C030010	RF COIL	1.0 μH-K
L 7707	409P752010	SWITCH COIL	13.5MHz
L 8001	411D009020	FERRITE CORE FILTER	
L 8002	325C106050	PEAKING COIL	15 μH-J
L 8003	325C106090	PEAKING COIL	33 μH-J
L 901	411P001070	FERRITE LEAD	BF60T
L 903	411P001070	FERRITE LEAD	BF60T
L 904	321C030050	RF COIL	2.2 μH-K
L 905	325C121010	PEAKING COIL	6.8 μH-K
L 951	325D059060	PEAKING COIL	390 μH-K
L 952	321C041050	RF COIL	J1SC-3212-0.4
L 956	321C131080	RF COIL	47MHz+-7.5%
L 958	411D009020	FERRITE CORE FILTER	
△L 991	351P011020	LINE FILTER	
△L 992	351P092010	LINE FILTER	253Y2R0-01
△L 996	351P092010	LINE FILTER	253Y2R0-01
LC201	320P051010	TRAP COIL	4.43MHz
LC202	320P051020	TRAP COIL	4.28MHz
LC2A1	320P051030	TRAP COIL	3.58MHz
LC2A2	320P051020	TRAP COIL	4.28MHz
LC2A3	320P051010	TRAP COIL	4.43MHz
LC7Y1	320P051010	TRAP COIL	4.43MHz
LC7003	409P402030	EMI FILTER	DSS306-55FZ103N100
LC7004	409P402030	EMI FILTER	DSS306-55FZ103N100
LC7005	409P402030	EMI FILTER	DSS306-55FZ103N100
LC7006	409P402030	EMI FILTER	DSS306-55FZ103N100
LC7007	409P402030	EMI FILTER	DSS306-55FZ103N100
LC7008	409P402030	EMI FILTER	DSS306-55FZ103N100
LC7009	409P402010	EMI FILTER	DSS306-55B101M100
LC7010	409P402010	EMI FILTER	DSS306-55B101M100
LC7011	409P402040	EMI FILTER	DSS306-54B470M100
		TRANSFORMERS	
LC7001	349P159050	CHROMA-BP	
LC7002	349P159010	CHROMA-BP	
T 551	336P009030	H.DRIVE	
△T 552	334P183040	FLYBACK	
T 5501	409P567010	FOCUS	

SYMBOL NO.	PARTS NO.	PARTS NAME	DESCRIPTION
△T 901	350P481030	POWER	
△T 902	336P023010	DRIVE	POWER
		VARIABLE RESISTORS	
VR201	127C081000	VR-SEMIFIXED	1/5W B30KΩ-M
VR202	127C080060	VR-SEMIFIXED	1/5W B3KΩ-M
VR451	127C180070	VR-SEMIFIXED	1/5W B5KΩ-M
VR452	127C191000	VR-SEMIFIXED	1/5W B30KΩ-M
VR501	127C080040	VR-SEMIFIXED	1/5W B1KΩ-M
VR5001	127C180040	VR-SEMIFIXED	1/5W B1KΩ-M
VR5002	127C181060	VR-SEMIFIXED	1/5W B1MΩ-M
VR5003	127C180070	VR-SEMIFIXED	1/5W B5KΩ-M
VR601	127C080050	VR-SEMIFIXED	1/5W B2KΩ-M
VR602	127C080070	VR-SEMIFIXED	1/5W B5KΩ-M
VR603	127C080080	VR-SEMIFIXED	1/5W B10KΩ-M
VR651	127C020040	VR-SEMIFIXED	1/5W B1KΩ-N
VR652	127C020040	VR-SEMIFIXED	1/5W B1KΩ-N
VR653	127C020040	VR-SEMIFIXED	1/5W B1KΩ-N
VR654	127C020050	VR-SEMIFIXED	1/5W B2KΩ-N
VR655	127C020050	VR-SEMIFIXED	1/5W B2KΩ-N
VR6001	127C090040	VR-SEMIFIXED	1/5W B1KΩ-M
VR6002	127C090040	VR-SEMIFIXED	1/5W B1KΩ-M
VR6003	127C090040	VR-SEMIFIXED	1/5W B1KΩ-M
VR6004	127C090040	VR-SEMIFIXED	1/5W B1KΩ-M
VR6005	127C090030	VR-SEMIFIXED	1/5W B500Ω-M
VR6006	127C090040	VR-SEMIFIXED	1/5W B1KΩ-M
VR6007	127C090040	VR-SEMIFIXED	1/5W B1KΩ-M
VR6008	127C090050	VR-SEMIFIXED	1/5W B2KΩ-M
VR7001	127C080080	VR-SEMIFIXED	1/5W B10KΩ-M
VR7002	127C080010	VR-SEMIFIXED	1/5W B200Ω-M
VR7003	127C080070	VR-SEMIFIXED	1/5W B5KΩ-M
VR7701	127C180080	VR-SEMIFIXED	1/10W B10KΩ-M
VR951	127C080080	VR-SEMIFIXED	1/5W B10KΩ-M
		RESISTORS	
R 322	109P052010	FUSE	1/4W 100Ω-J
R 323	109P052010	FUSE	1/4W 100Ω-J
R 3C7	103P586010	NETWORK	1/8W 1MΩ-J
R 3C8	103P586010	NETWORK	1/8W 1MΩ-J
△R 451	103P378040	FUSE	1/4W 2.2Ω-J
R 551	109D067070	CEMENT WIRE	10W 2.7Ω-K
△R 553	103P442020	FUSE METAL	1W 560Ω-K/J
△R 554	109P052040	FUSE	1/4W 1.2Ω-J
△R 555	103P398010	FUSE	1/2W 1.2Ω-J
△R 556	103P397090	FUSE	1/2W 0.82Ω-J
△R 559	103P392050	FUSE	1/2W 1.0KΩ-J
R 566	102P172080	CEMENT METAL	5W 1.8KΩ-K/J
△R 568	103P397090	FUSE	1/2W 0.82Ω-J
△R 570	103P392020	FUSE	1/2W 560Ω-J
△R 5519	103P392050	FUSE	1/2W 1.0KΩ-J
△R 671	103P438030	FUSE METAL	2W 1.8Ω-K/J
△R 675	103P372050	FUSE	1/4W 1KΩ-J
△R 676	103P372050	FUSE	1/4W 1KΩ-J
△R 677	103P372050	FUSE	1/4W 1KΩ-J
R 701	103P623040	NETWORK	1/8W 5.6KΩ-J

SYMBOL NO.	PARTS NO.	PARTS NAME	DESCRIPTION
R 716	103P583030	NETWORK	1/8W 4.7KΩ-J
△R 8014	103P370010	FUSE	1/4W 10Ω-J
△R 8015	103P370050	FUSE	1/4W 22Ω-J
△R 8016	103P370010	FUSE	1/4W 10Ω-J
R 901	102P083010	CEMENT WIRE	10W 2.2Ω-K
R 906	109D075060	CEMENT WIRE	10W 1KΩ-J
△R 960	103P397090	FUSE	1/2W 0.82Ω-J
R 992	102P082080	CEMENT WIRE	10W 2.7Ω-K
		CAPACITORS AND TRIMMERS	
C 557	189P071080	C-M-PLASTIC-PP	200V 0.47μF-J
C 558	189P071010	C-M-PLASTIC-PP	200V 0.56μF-J
C 559	189P081030	C-M-PLASTIC-PP	200V 0.82μF-J
C 560	189P071020	C-M-PLASTIC-PP	200V 0.51μF-J
C 567	189P081020	C-M-PLASTIC-PP	200V 0.22μF-J
C 710	189P092010	ELECTROLYTIC-C	FU5.5V 0.047μF-Z
C 904	185D062070	ELECTROLYTIC-C	450DV 330μF-M
△C 913	189P091010	CERAMIC CAPACITOR	AC400V E4700pF-M
CR971	149P008010	CR-MULTIPLE	470pF&3.6μF-K
VC3001	202P109030	TRIMMER CAPACITOR	5.5pF-30pF
VC3002	202P109030	TRIMMER CAPACITOR	5.5pF-30pF
VC701	202P109050	TRIMMER CAPACITOR	9.8pF-60pF
VC7001	202P109030	TRIMMER CAPACITOR	5.5pF-30pF
VC7002	202P109030	TRIMMER CAPACITOR	5.5pF-30pF
		SWITCHES	
S 2001	129P007090	VR-CH-PRESETTER	SW-BAND
S 3A1	432P052030	PUSH SWITCH	2-2 LOCK-TYPE
S 3A2	432P052030	PUSH SWITCH	2-2 LOCK-TYPE
S 401	129P007090	VR-CH-PRESETTER	SW-BAND
S 7Y1	432P101010	KEY BOARD SWITCH	1-1 H=4.3
S 7Y2	432P101010	KEY BOARD SWITCH	1-1 H=4.3
S 7Y3	432P101010	KEY BOARD SWITCH	1-1 H=4.3
S 7Y4	432P101010	KEY BOARD SWITCH	1-1 H=4.3
S 7Y5	432P101010	KEY BOARD SWITCH	1-1 H=4.3
S 7Y7	432P101010	KEY BOARD SWITCH	1-1 H=4.3
S 7Y8	432P101010	KEY BOARD SWITCH	1-1 H=4.3
S 7Z0	431C068030	SLIDE SWITCH	2-3 NON-SHORT
S 7Z1	431C067010	SLIDE SWITCH	2-2 NON SHORT
S 7Z2	432P101010	KEY BOARD SWITCH	1-1 H=4.3
S 7Z5	432C038020	PUSH SWITCH	
△S 991	432P076030	PUSH SWITCH	2-1 AC250V 5A L18
		MISCELLANEOUS	
	338P025020	CPM ASSY	
	641D758010	WEDGE	3P DEF-YOKE SETTING
△F 991	283D091040	FUSE	T2A
IP101	295P097010	TUNER HF PACK	
J 2A1	451C058010	CONNECTOR	21P
J 2A2	451C058010	CONNECTOR	21P
J 2A3	449C102010	SOCKET DIN MINI	4P
J 3A1	451C114010	PIN JACK(2P)	RED+WHITE
J 3A2	440C191010	PUSH TERMINAL 8P	
J 3Y1	451C119010	HEADPHONE JACK	
△J 601	449C085010	CRT SOCKET	

SYMBOL NO.	PARTS NO.	PARTS NAME	DESCRIPTION
J 7Y2	451C114010	PIN JACK(2P)	RED+WHITE
J 7Y3	451C106050	PIN JACK	
J 7Y1	449C093010	SOCKET DIN MINI	4P (S+SW)
K 301	287P060010	POWER RELAY	DH12D2-DS(M)
⚠K 9A1	287P029050	POWER RELAY	
X 3001	285P092010	CRYSTAL RESONATOR	5.85MHz
X 3002	285P093010	CRYSTAL RESONATOR	5.824MHz
X 601	285P132010	CRYSTAL RESONATOR	4.4336MHz
X 602	285P131010	CRYSTAL RESONATOR	3.5795MHz
X 6001	285P079010	CRYSTAL RESONATOR	21.325MHz
X 701	285P063040	CRYSTAL RESONATOR	4.19430MHz
X 702	285P073020	CRYSTAL RESONATOR	7.15909MHz
X 7001	285P073020	CRYSTAL RESONATOR	7.15909MHz
X 7002	285P068030	CRYSTAL RESONATOR	8.8MHz
X 7701	285P062030	CRYSTAL RESONATOR	13.875MHz
X 7702	285P139010	CRYSTAL RESONATOR	12MHz
⚠Z 5001	299P087060	SURGE PROTECTOR	PRF 2000
Z 701	939P226010	PREAMP UNIT	SBX1483
⚠Z 950	299P132010	SURGE PROTECTOR	PRF 5000
⚠Z 951	299P087060	SURGE PROTECTOR	PRF 3150
⚠Z 952	299P132010	SURGE PROTECTOR	PRF 5000
⚠Z 953	299P132010	SURGE PROTECTOR	PRF 5000
		PRINTED CIRCUIT BOARD ASSY'S	
⚠	930D015001	A/V SW PCB ASSY	
⚠	920D276090	ADG PCB ASSY	
⚠	920D278090	AV PCB ASSY	
⚠	920D311040	CONTROL PCB ASSY	
⚠	930C377001	DCF PCB ASSY	
⚠	920D277090	DEFL REG PCB ASSY	
⚠	930C498002	NICAM PCB ASSY	
⚠	930C381001	PCC/DBF PCB ASSY	
⚠	930C378001	PIP PCB ASSY	
⚠	920D310090	POWER SUB PCB ASSY	
⚠	930C608005	SIGNAL PCB ASSY	
⚠	930C607002	SW PCB ASSY	
⚠	930C441001	TERMINAL PCB ASSY	
⚠	930C382001	VMCRT PCB ASSY	
⚠	920D280050	Y/C-SW PCB ASSY	
⚠	920D279050	YUV PCB ASSY	
		MECHANICAL PARTS	
	6690107010	SCREW	M3X12
	6690130020	SCREW	4X16
	6690220010	SCREW	3X6 46LA005
	6690220020	SCREW	3X8 46LA005
	6690220030	SCREW	3X10 46LA005
	6690221080	SCREW	4X16 46LA005
	6690212010	SCREW	3X12
	6690212040	SCREW	3X10
	6690222060	SCREW	3X16-12
		COSMETIC PARTS	
⚠	246C022030	AC POWER CORD	
	702C949010	CONTROL CASE ASSY	

SYMBOL NO.	PARTS NO.	PARTS NAME	DESCRIPTION
⚠	700C147040	BACK COVER	
	701D086070	FRONT CABINET ASSY	
	224D243010	CRT CAP	
	641D173010	CLIP	AC POWER CORDE
	702D225080	CONTROL DOOR ASSY	
	704C738010	POWER KNOB	
	734D283010	PUSH KNOB	
	734D284010	PUSH KNOB	
	734D353010	SLIDE KNOB	
	701B258030	FRONT PANEL	
	926P013080	SPEAKER SYSTEM	
	761A078080	TERMINAL BOARD	
	761D628010	SPEAKER HOLDER	
		PACKING PARTS AND ACCESSORY	
	803A325010	PACKING CUSHION	
	802B395010	PACKING CASE	
	802B395060	PACKING CASE	
	831D110090	PACKING BAG	
	831D174090	PACKING BAG	
	244D229010	CABLE	VFF L=1500 2P
⚠	872C083000	INSTRUCTION BOOK	
⚠	939P486010	REMOTE HAND UNIT	

〔MEMO〕

LEAD DRESSING

The lead wires to be clamped are listed in the table below.

Note: The inner wires are clamped so that they do not come close to the heat generating or high-tension parts. After servicing route all wires in their original position.

The anode lead wires are routed so no tensile strength is applied to the anode cap. If the mounting angle of the anode cap and the route of the anode lead wires are changed, return them to the initial angle and route.

CONNECTOR LEAD FOR CLAMP

CLAMP	LEAD TO BE CLAMPED
A	DC,KY,PE,PJ,NS,DB,SC
B	EARTH LEAD FROM SA,SC,DC,KY,PE, PJ,NS,DB,YP,FP,FK,SM,FH
C	SN,SD,LD2,AU2,ST,KY,PJ,SC
D	AP
F	KY,PJ,EP,PF
G	KY,PJ,EP,PF
J	KY,PJ,EP,LD,RA,PF
K	PT,PJ,EP,LD,RA,AP,PF
L	EP,LD,RA,PT,EA,AP,PF
M	EP,LD,RA,PC,PT,EA
N	EP,LD,RA,PC,PT,PL,EA
P	EP,LD,RA,PC,PT,PL,EA
Q	PT,PJ,AP,DA,CA,SM,TD
R	PJ,DA,CA,CT,AP,PA,LP,CM,FH,FK,SM,TD
S	DB,DC,FP,FK,SM,YP,FH
T	DC,DB,CT,PA,CB,CC,CA,AE,AD,AC,AF, LP,DA,AY,AL,AP,FK,FP,FH,SM,YP
U	YP,DC,LP,DA,AP,AK,FP,FK,SM,DB,FH(2 LAYERS CLAMP)
V	KY,PJ,SC,SN,SD,LD2,AU2,ST
W	PY,CX,DV,DF1,TD,LEADS FROM DY
Y	PE,SC,KY,PJ
Z	PE
a	ANODE LEAD
b	ANODE LEAD
d	ANODE LEAD
e	PE,PY,CX,LEADS FROM DY
g	DF1
h	PT,PG,PL,PY,EP,RA,LD, EA,PC,FROM DG-COIL
j	PJ,NS
k	FP,FK,SM,LEADS FROM DG-COIL
l	DF2,F1,F2,G2,DF1,SB
n	FP
r	FP,FK,SM,YP,FH,NS
t	PS,SA,LEADS FROM DY
v	SA,CA,F1,F2,DF2,SB,MY,PS(2 LAYER CLAMP)
w	SA,PS,CC,CB,CT,PA,CA(2 LAYER CLAMP)
x	SC,EP
y	F1,F2,DF2,G2,PS
AA	SB
BB	SB
CC	DV,DF1
JJ	DA,CC,CA,CB,CT,AP,PA,LP,FP,CM,FH,FK,SM,TD
KK	AV, AW















gh-tension parts. After servicing route all

ng angle of the anode cap and the route of







CLAMP FOR CONNECTOR LEAD

CONNECTOR	CLAMP
ANODE LEAD	a-b-d
AC	T
AD	T
AE	T
AF	T
AK	U
AL	T
AP	L-K-Q-R-JJ-T-U-D
AU2	V-C
AT	T
AY	T
CA	v-w-Q-R-JJ-T
CB	w-JJ-T
CC	w-JJ-T
CM	R-JJ
CT	w-R-JJ-T
CX	e-W
DA	U-Q-R-JJ-T
DB	A-B-S-U-T
DC	A-B-S-U-T
DF1	W-cc-g-l
DF2	y-v-l
DV	W-cc
EA	L-M-N-P-h
EP	x-F-G-J-K-L-M-N-P-h
F1	y-v-l
F2	y-v-l
FH	r-B-S-U(2 LAYERS CLAMP)-T-JJ-R
FK	k-r-B-S-U-T-JJ-R
FP	n-k-r-B-S-U-T-JJ
G2	l-y
KY	A-B-Y-V-C-F-G-J
LD	J-K-L-M-N-P-h
LD2	V-C
LP	U-T-JJ-R
MY	v
NS	j-A-B-r
PA	w-T-JJ-R
PC	M-N-P
PE	A-B-Y-Z-e
PF	F-G-J-K-L
PG	h
PJ	j-A-B-Y-V-C-F-G-J-K-Q-R
PL	N-P-h
PS	w-v(2 LAYERS CLAMP)-t-y
PT	Q-K-L-M-N-P-h
PY	e-h-W
RA	J-K-L-M-N-P-h
SA	t-v-w(2 LAYERS CLAMP)
SB	v-l-AA-BB
SC	A-B-Y-V-C-X
SD	V-C
SM	k-r-B-S-U-T-JJ-R-Q
SN	V-C
ST	V-C
TD	Q-R-JJ-W
YP	r-B-S-U-T
AV	KK
AW	KK


1
2
3
4
5
6
7
A
B
C
D
E
TERMINAL
SOUND OUT
MICON
IC301
IC701
IC709
IC201
IC202
IC203
IC204
IC205
IC206
IC207
IC208
IC209
IC210
IC211
IC212
IC213
IC214
IC215
IC216
IC217
IC218
IC219
IC220
IC221
IC222
IC223
IC224
IC225
IC226
IC227
IC228
IC229
IC230
IC231
IC232
IC233
IC234
IC235
IC236
IC237
IC238
IC239
IC240
IC241
IC242
IC243
IC244
IC245
IC246
IC247
IC248
IC249
IC250
IC251
IC252
IC253
IC254
IC255
IC256
IC257
IC258
IC259
IC260
IC261
IC262
IC263
IC264
IC265
IC266
IC267
IC268
IC269
IC270
IC271
IC272
IC273
IC274
IC275
IC276
IC277
IC278
IC279
IC280
IC281
IC282
IC283
IC284
IC285
IC286
IC287
IC288
IC289
IC290
IC291
IC292
IC293
IC294
IC295
IC296
IC297
IC298
IC299
IC300
IC301
IC302
IC303
IC304
IC305
IC306
IC307
IC308
IC309
IC310
IC311
IC312
IC313
IC314
IC315
IC316
IC317
IC318
IC319
IC320
IC321
IC322
IC323
IC324
IC325
IC326
IC327
IC328
IC329
IC330
IC331
IC332
IC333
IC334
IC335
IC336
IC337
IC338
IC339
IC340
IC341
IC342
IC343
IC344
IC345
IC346
IC347
IC348
IC349
IC350
IC351
IC352
IC353
IC354
IC355
IC356
IC357
IC358
IC359
IC360
IC361
IC362
IC363
IC364
IC365
IC366
IC367
IC368
IC369
IC370
IC371
IC372
IC373
IC374
IC375
IC376
IC377
IC378
IC379
IC380
IC381
IC382
IC383
IC384
IC385
IC386
IC387
IC388
IC389
IC390
IC391
IC392
IC393
IC394
IC395
IC396
IC397
IC398
IC399
IC400
IC401
IC402
IC403
IC404
IC405
IC406
IC407
IC408
IC409
IC410
IC411
IC412
IC413
IC414
IC415
IC416
IC417
IC418
IC419
IC420
IC421
IC422
IC423
IC424
IC425
IC426
IC427
IC428
IC429
IC430
IC431
IC432
IC433
IC434
IC435
IC436
IC437
IC438
IC439
IC440
IC441
IC442
IC443
IC444
IC445
IC446
IC447
IC448
IC449
IC450
IC451
IC452
IC453
IC454
IC455
IC456
IC457
IC458
IC459
IC460
IC461
IC462
IC463
IC464
IC465
IC466
IC467
IC468
IC469
IC470
IC471
IC472
IC473
IC474
IC475
IC476
IC477
IC478
IC479
IC480
IC481
IC482
IC483
IC484
IC485
IC486
IC487
IC488
IC489
IC490
IC491
IC492
IC493
IC494
IC495
IC496
IC497
IC498
IC499
IC500
IC501
IC502
IC503
IC504
IC505
IC506
IC507
IC508
IC509
IC510
IC511
IC512
IC513
IC514
IC515
IC516
IC517
IC518
IC519
IC520
IC521
IC522
IC523
IC524
IC525
IC526
IC527
IC528
IC529
IC530
IC531
IC532
IC533
IC534
IC535
IC536
IC537
IC538
IC539
IC540
IC541
IC542
IC543
IC544
IC545
IC546
IC547
IC548
IC549
IC550
IC551
IC552
IC553
IC554
IC555
IC556
IC557
IC558
IC559
IC560
IC561
IC562
IC563
IC564
IC565
IC566
IC567
IC568
IC569
IC570
IC571
IC572
IC573
IC574
IC575
IC576
IC577
IC578
IC579
IC580
IC581
IC582
IC583
IC584
IC585
IC586
IC587
IC588
IC589
IC590
IC591
IC592
IC593
IC594
IC595
IC596
IC597
IC598
IC599
IC600
IC601
IC602
IC603
IC604
IC605
IC606
IC607
IC608
IC609
IC610
IC611
IC612
IC613
IC614
IC615
IC616
IC617
IC618
IC619
IC620
IC621
IC622
IC623
IC624
IC625
IC626
IC627
IC628
IC629
IC630
IC631
IC632
IC633
IC634
IC635
IC636
IC637
IC638
IC639
IC640
IC641
IC642
IC643
IC644
IC645
IC646
IC647
IC648
IC649
IC650
IC651
IC652
IC653
IC654
IC655
IC656
IC657
IC658
IC659
IC660
IC661
IC662
IC663
IC664
IC665
IC666
IC667
IC668
IC669
IC670
IC671
IC672
IC673
IC674
IC675
IC676
IC677
IC678
IC679
IC680
IC681
IC682
IC683
IC684
IC685
IC686
IC687
IC688
IC689
IC690
IC691
IC692
IC693
IC694
IC695
IC696
IC697
IC698
IC699
IC700
IC701
IC702
IC703
IC704
IC705
IC706
IC707
IC708
IC709
IC710
IC711
IC712
IC713
IC714
IC715
IC716
IC717
IC718
IC719
IC720
IC721
IC722
IC723
IC724
IC725
IC726
IC727
IC728
IC729
IC730
IC731
IC732
IC733
IC734
IC735
IC736
IC737
IC738
IC739
IC740
IC741
IC742
IC743
IC744
IC745
IC746
IC747
IC748
IC749
IC750
IC751
IC752
IC753
IC754
IC755
IC756
IC757
IC758
IC759
IC760
IC761
IC762
IC763
IC764
IC765
IC766
IC767
IC768
IC769
IC770
IC771
IC772
IC773
IC774
IC775
IC776
IC777
IC778
IC779
IC780
IC781
IC782
IC783
IC784
IC785
IC786
IC787
IC788
IC789
IC790
IC791
IC792
IC793
IC794
IC795
IC796
IC797
IC798
IC799
IC800
IC801
IC802
IC803
IC804
IC805
IC806
IC807
IC808
IC809
IC810
IC811
IC812
IC813
IC814
IC815
IC816
IC817
IC818
IC819
IC820
IC821
IC822
IC823
IC824
IC825
IC826
IC827
IC828
IC829
IC830
IC831
IC832
IC833
IC834
IC835
IC836
IC837
IC838
IC839
IC840
IC841
IC842
IC843
IC844
IC845
IC846
IC847
IC848
IC849
IC850
IC851
IC852
IC853
IC854
IC855
IC856
IC857
IC858
IC859
IC860
IC861
IC862
IC863
IC864
IC865
IC866
IC867
IC868
IC869
IC870
IC871
IC872
IC873
IC874
IC875
IC876
IC877
IC878
IC879
IC880
IC881
IC882
IC883
IC884
IC885
IC886
IC887
IC888
IC889
IC890
IC891
IC892
IC893
IC894
IC895
IC896
IC897
IC898
IC899
IC900
IC901
IC902
IC903
IC904
IC905
IC906
IC907
IC908
IC909
IC910
IC911
IC912
IC913
IC914
IC915
IC916
IC917
IC918
IC919
IC920
IC921
IC922
IC923
IC924
IC925
IC926
IC927
IC928
IC929
IC930
IC931
IC932
IC933
IC934
IC935
IC936
IC937
IC938
IC939
IC940
IC941
IC942
IC943
IC944
IC945
IC946
IC947
IC948
IC949
IC950
IC951
IC952
IC953
IC954
IC955
IC956
IC957
IC958
IC959
IC960
IC961
IC962
IC963
IC964
IC965
IC966
IC967
IC968
IC969
IC970
IC971
IC972
IC973
IC974
IC975
IC976
IC977
IC978
IC979
IC980
IC981
IC982
IC983
IC984
IC985
IC986
IC987
IC988
IC989
IC990
IC991
IC992
IC993
IC994
IC995
IC996
IC997
IC998
IC999
IC1000

PCB SIGNAL


PCB YC/SW
PCB LED
PCB EPJ
PCB PREAMP
PCB YUV
PCB AV
PCB CONTROL


1
2
3
4
5
6
7
A
B
C
D
E
PCB ADG
J 240A77301
CMK-140X-PA▲
PC
PE
PF
PG
PH
IC5A1
ADG
PCB POWER SUB
F991 T2A
T2AH 250V
PX
POWER-SUB
PCO/DBF
DEFL/REG
PZ1
PZ2
IC5B1
IC5C1
IC5D1
IC5E1
IC5F1
IC5G1
IC5H1
IC5J1
IC5K1
IC5L1
IC5M1
IC5N1
IC5P1
IC5Q1
IC5R1
IC5S1
IC5T1
IC5U1
IC5V1
IC5W1
IC5X1
IC5Y1
IC5Z1
IC6A1
IC6B1
IC6C1
IC6D1
IC6E1
IC6F1
IC6G1
IC6H1
IC6J1
IC6K1
IC6L1
IC6M1
IC6N1
IC6P1
IC6Q1
IC6R1
IC6S1
IC6T1
IC6U1
IC6V1
IC6W1
IC6X1
IC6Y1
IC6Z1
IC7A1
IC7B1
IC7C1
IC7D1
IC7E1
IC7F1
IC7G1
IC7H1
IC7J1
IC7K1
IC7L1
IC7M1
IC7N1
IC7P1
IC7Q1
IC7R1
IC7S1
IC7T1
IC7U1
IC7V1
IC7W1
IC7X1
IC7Y1
IC7Z1
IC8A1
IC8B1
IC8C1
IC8D1
IC8E1
IC8F1
IC8G1
IC8H1
IC8J1
IC8K1
IC8L1
IC8M1
IC8N1
IC8P1
IC8Q1
IC8R1
IC8S1
IC8T1
IC8U1
IC8V1
IC8W1
IC8X1
IC8Y1
IC8Z1
IC9A1
IC9B1
IC9C1
IC9D1
IC9E1
IC9F1
IC9G1
IC9H1
IC9J1
IC9K1
IC9L1
IC9M1
IC9N1
IC9P1
IC9Q1
IC9R1
IC9S1
IC9T1
IC9U1
IC9V1
IC9W1
IC9X1
IC9Y1
IC9Z1
IC10A1
IC10B1
IC10C1
IC10D1
IC10E1
IC10F1
IC10G1
IC10H1
IC10J1
IC10K1
IC10L1
IC10M1
IC10N1
IC10P1
IC10Q1
IC10R1
IC10S1
IC10T1
IC10U1
IC10V1
IC10W1
IC10X1
IC10Y1
IC10Z1
IC11A1
IC11B1
IC11C1
IC11D1
IC11E1
IC11F1
IC11G1
IC11H1
IC11J1
IC11K1
IC11L1
IC11M1
IC11N1
IC11P1
IC11Q1
IC11R1
IC11S1
IC11T1
IC11U1
IC11V1
IC11W1
IC11X1
IC11Y1
IC11Z1
IC12A1
IC12B1
IC12C1
IC12D1
IC12E1
IC12F1
IC12G1
IC12H1
IC12J1
IC12K1
IC12L1
IC12M1
IC12N1
IC12P1
IC12Q1
IC12R1
IC12S1
IC12T1
IC12U1
IC12V1
IC12W1
IC12X1
IC12Y1
IC12Z1
IC13A1
IC13B1
IC13C1
IC13D1
IC13E1
IC13F1
IC13G1
IC13H1
IC13J1
IC13K1
IC13L1
IC13M1
IC13N1
IC13P1
IC13Q1
IC13R1
IC13S1
IC13T1
IC13U1
IC13V1
IC13W1
IC13X1
IC13Y1
IC13Z1
IC14A1
IC14B1
IC14C1
IC14D1
IC14E1
IC14F1
IC14G1
IC14H1
IC14J1
IC14K1
IC14L1
IC14M1
IC14N1
IC14P1
IC14Q1
IC14R1
IC14S1
IC14T1
IC14U1
IC14V1
IC14W1
IC14X1
IC14Y1
IC14Z1
IC15A1
IC15B1
IC15C1
IC15D1
IC15E1
IC15F1
IC15G1
IC15H1
IC15J1
IC15K1
IC15L1
IC15M1
IC15N1
IC15P1
IC15Q1
IC15R1
IC15S1
IC15T1
IC15U1
IC15V1
IC15W1
IC15X1
IC15Y1
IC15Z1
IC16A1
IC16B1
IC16C1
IC16D1
IC16E1
IC16F1
IC16G1
IC16H1
IC16J1
IC16K1
IC16L1
IC16M1
IC16N1
IC16P1
IC16Q1
IC16R1
IC16S1
IC16T1
IC16U1
IC16V1
IC16W1
IC16X1
IC16Y1
IC16Z1
IC17A1
IC17B1
IC17C1
IC17D1
IC17E1
IC17F1
IC17G1
IC17H1
IC17J1
IC17K1
IC17L1
IC17M1
IC17N1
IC17P1
IC17Q1
IC17R1
IC17S1
IC17T1
IC17U1
IC17V1
IC17W1
IC17X1
IC17Y1
IC17Z1
IC18A1
IC18B1
IC18C1
IC18D1
IC18E1
IC18F1
IC18G1
IC18H1
IC18J1
IC18K1
IC18L1
IC18M1
IC18N1
IC18P1
IC18Q1
IC18R1
IC18S1
IC18T1
IC18U1
IC18V1
IC18W1
IC18X1
IC18Y1
IC18Z1
IC19A1
IC19B1
IC19C1
IC19D1
IC19E1
IC19F1
IC19G1
IC19H1
IC19J1
IC19K1
IC19L1
IC19M1
IC19N1
IC19P1
IC19Q1
IC19R1
IC19S1
IC19T1
IC19U1
IC19V1
IC19W1
IC19X1
IC19Y1
IC19Z1
IC20A1
IC20B1
IC20C1
IC20D1
IC20E1
IC20F1
IC20G1
IC20H1
IC20J1
IC20K1
IC20L1
IC20M1
IC20N1
IC20P1
IC20Q1
IC20R1
IC20S1
IC20T1
IC20U1
IC20V1
IC20W1
IC20X1
IC20Y1
IC20Z1
IC21A1
IC21B1
IC21C1
IC21D1
IC21E1
IC21F1
IC21G1
IC21H1
IC21J1
IC21K1
IC21L1
IC21M1
IC21N1
IC21P1
IC21Q1
IC21R1
IC21S1
IC21T1
IC21U1
IC21V1
IC21W1
IC21X1
IC21Y1
IC21Z1
IC22A1
IC22B1
IC22C1
IC22D1
IC22E1
IC22F1
IC22G1
IC22H1
IC22J1
IC22K1
IC22L1
IC22M1
IC22N1
IC22P1
IC22Q1
IC22R1
IC22S1
IC22T1
IC22U1
IC22V1
IC22W1
IC22X1
IC22Y1
IC22Z1
IC23A1
IC23B1
IC23C1
IC23D1
IC23E1
IC23F1
IC23G1
IC23H1
IC23J1
IC23K1
IC23L1
IC23M1
IC23N1
IC23P1
IC23Q1
IC23R1
IC23S1
IC23T1
IC23U1
IC23V1
IC23W1
IC23X1
IC23Y1
IC23Z1
IC24A1
IC24B1
IC24C1
IC24D1
IC24E1
IC24F1
IC24G1
IC24H1
IC24J1
IC24K1
IC24L1
IC24M1
IC24N1
IC24P1
IC24Q1
IC24R1
IC24S1
IC24T1
IC24U1
IC24V1
IC24W1
IC24X1
IC24Y1
IC24Z1
IC25A1
IC25B1
IC25C1
IC25D1
IC25E1
IC25F1
IC25G1
IC25H1
IC25J1
IC25K1
IC25L1
IC25M1
IC25N1
IC25P1
IC25Q1
IC25R1
IC25S1
IC25T1
IC25U1
IC25V1
IC25W1
IC25X1
IC25Y1
IC25Z1
IC26A1
IC26B1
IC26C1
IC26D1
IC26E1
IC26F1
IC26G1
IC26H1
IC26J1
IC26K1
IC26L1
IC26M1
IC26N1
IC26P1
IC26Q1
IC26R1
IC26S1
IC26T1
IC26U1
IC26V1
IC26W1
IC26X1
IC26Y1
IC26Z1
IC27A1
IC27B1
IC27C1
IC27D1
IC27E1
IC27F1
IC27G1
IC27H1
IC27J1
IC27K1
IC27L1
IC27M1
IC27N1
IC27P1
IC27Q1
IC27R1
IC27S1
IC27T1
IC27U1
IC27V1
IC27W1
IC27X1
IC27Y1
IC27Z1
IC28A1
IC28B1
IC28C1
IC28D1
IC28E1
IC28F1
IC28G1
IC28H1
IC28J1
IC28K1
IC28L1
IC28M1
IC28N1
IC28P1
IC28Q1
IC28R1
IC28S1
IC28T1
IC28U1
IC28V1
IC28W1
IC28X1
IC28Y1
IC28Z1
IC29A1
IC29B1
IC29C1
IC29D1
IC29E1
IC29F1
IC29G1
IC29H1
IC29J1
IC29K1
IC29L1
IC29M1
IC29N1
IC29P1
IC29Q1
IC29R1
IC29S1
IC29T1
IC29U1
IC29V1
IC29W1
IC29X1
IC29Y1
IC29Z1
IC30A1
IC30B1
IC30C1
IC30D1
IC30E1
IC30F1
IC30G1
IC30H1
IC30J1
IC30K1
IC30L1
IC30M1
IC30N1
IC30P1
IC30Q1
IC30R1
IC30S1
IC30T1
IC30U1
IC30V1
IC30W1
IC30X1
IC30Y1
IC30Z1
IC31A1
IC31B1
IC31C1
IC31D1
IC31E1
IC31F1
IC31G1
IC31H1
IC31J1
IC31K1
IC31L1
IC31M1
IC31N1
IC31P1
IC31Q1
IC31R1
IC31S1
IC31T1
IC31U1
IC31V1
IC31W1
IC31X1
IC31Y1
IC31Z1
IC32A1
IC32B1
IC32C1
IC32D1
IC32E1
IC32F1
IC32G1
IC32H1
IC32J1
IC32K1
IC32L1
IC32M1
IC32N1
IC32P1
IC32Q1
IC32R1
IC32S1
IC32T1
IC32U1
IC32V1
IC32W1
IC32X1
IC32Y1
IC32Z1
IC33A1
IC33B1
IC33C1
IC33D1
IC33E1
IC33F1
IC33G1
IC33H1
IC33J1
IC33K1
IC33L1
IC33M1
IC33N1
IC33P1
IC33Q1
IC33R1
IC33S1
IC33T1
IC33U1
IC33V1
IC33W1
IC33X1
IC33Y1
IC33Z1
IC34A1
IC34B1
IC34C1
IC34D1
IC34E1
IC34F1
IC34G1
IC34H1
IC34J1
IC34K1
IC34L1
IC34M1
IC34N1
IC34P1
IC34Q1
IC34R1
IC34S1
IC34T1
IC34U1
IC34V1
IC34W1
IC34X1
IC34Y1
IC34Z1
IC35A1
IC35B1
IC35C1
IC35D1
IC35E1
IC35F1
IC35G1
IC35H1
IC35J1
IC35K1
IC35L1
IC35M1
IC35N1
IC35P1
IC35Q1
IC35R1
IC35S1
IC35T1
IC35U1
IC35V1
IC35W1
IC35X1
IC35Y1
IC35Z1
IC36A1
IC36B1
IC36C1
IC36D1
IC36E1
IC36F1
IC36G1
IC36H1
IC36J1
IC36K1
IC36L1
IC36M1
IC36N1
IC36P1
IC36Q1
IC36R1
IC36S1
IC36T1
IC36U1
IC36V1
IC36W1
IC36X1
IC36Y1
IC36Z1
IC37A1
IC37B1
IC37C1
IC37D1
IC37E1
IC37F1
IC37G1
IC37H1
IC37J1
IC37K1
IC37L1
IC37M1
IC37N1
IC37P1
IC37Q1
IC37R1
IC37S1
IC37T1
IC37U1
IC37V1
IC37W1
IC37X1
IC37Y1
IC37Z1
IC38A1
IC38B1
IC38C1
IC38D1
IC38E1
IC38F1
IC38G1
IC38H1
IC38J1
IC38K1
IC38L1
IC38M1
IC38N1
IC38P1
IC38Q1
IC38R1
IC38S1
IC38T1
IC38U1
IC38V1
IC38W1
IC38X1
IC38Y1
IC38Z1
IC39A1
IC39B1
IC39C1
IC39D1
IC39E1
IC39F1
IC39G1
IC39H1
IC39J1
IC39K1
IC39L1
IC39M1
IC39N1
IC39P1
IC39Q1
IC39R1
IC39S1
IC39T1
IC39U1
IC39V1
IC39W1
IC39X1
IC39Y1
IC39Z1
IC40A1
IC40B1
IC40C1
IC40D1
IC40E1
IC40F1
IC40G1
IC40H1
IC40J1
IC40K1
IC40L1
IC40M1
IC40N1
IC40P1
IC40Q1
IC40R1
IC40S1
IC40T1
IC40U1
IC40V1
IC40W1
IC40X1
IC40Y1
IC40Z1
IC41A1
IC41B1
IC41C1
IC41D1
IC41E1
IC41F1
IC41G1
IC41H1
IC41J1
IC41K1
IC41L1
IC41M1
IC41N1
IC41P1
IC41Q1
IC41R1
IC41S1
IC41T1
IC41U1
IC41V1
IC41W1
IC41X1
IC41Y1
IC41Z1
IC42A1
IC42B1
IC42C1
IC42D1
IC42E1
IC42F1
IC42G1
IC42H1
IC42J1
IC42K1
IC42L1
IC42M1
IC42N1
IC42P1
IC42Q1
IC42R1
IC42S1
IC42T1
IC42U1
IC42V1
IC42W1
IC42X1
IC42Y1
IC42Z1
IC43A1
IC43B1
IC43C1
IC43D1
IC43E1
IC43F1
IC43G1
IC43H1
IC43J1
IC43K1
IC43L1
IC43M1
IC43N1
IC43P1
IC43Q1
IC43R1
IC43S1
IC43T1
IC43U1
IC43V1
IC43W1
IC43X1
IC43Y1
IC43Z1
IC44A1
IC44B1
IC44C1
IC44D1
IC44E1
IC44F1
IC44G1
IC44H1
IC44J1
IC44K1
IC44L1
IC44M1
IC44N1
IC44P1
IC44Q1
IC44R1
IC44S1
IC44T1
IC44U1
IC44V1
IC44W1
IC44X1
IC44Y1
IC44Z1
IC45A1
IC45B1
IC45C1
IC45D1
IC45E1
IC45F1
IC45G1
IC45H1
IC45J1
IC45K1
IC45L1
IC45M1
IC45N1
IC45P1
IC45Q1
IC45R1
IC45S1
IC45T1
IC45U1
IC45V1
IC45W1
IC45X1
IC45Y1
IC45Z1
IC46A1
IC46B1
IC46C1
IC46D1
IC46E1
IC46F1
IC46G1
IC46H1
IC46J1
IC46K1
IC46L1
IC46M1
IC46N1
IC46P1
IC46Q1
IC46R1
IC46S1
IC46T1
IC46U1
IC46V1
IC46W1
IC46X1
IC46Y1
IC46Z1
IC47A1
IC47B1
IC47C1
IC47D1
IC47E1
IC47F1
IC47G1
IC47H1
IC47J1
IC47K1
IC47L1
IC47M1
IC47N1
IC47P1
IC47Q1
IC47R1
IC47S1
IC47T1
IC47U1
IC47V1
IC47W1
IC47X1
IC47Y1
IC47Z1
IC48A1
IC48B1
IC48C1
IC48D1
IC48E1
IC48F1
IC48G1
IC48H1
IC48J1
IC48K1
IC48L1
IC48M1
IC48N1
IC48P1
IC48Q1
IC48R1
IC48S1
IC48T1
IC48U1
IC48V1
IC48W1
IC48X1
IC48Y1
IC48Z1
IC49A1
IC49B1
IC49C1
IC49D1
IC49E1
IC49F1
IC49G1
IC49H1
IC49J1
IC49K1
IC49L1
IC49M1
IC49N1
IC49P1
IC49Q1
IC49R1
IC49S1
IC49T1
IC49U1
IC49V1
IC49W1
IC49X1
IC49Y1
IC49Z1
IC50A1
IC50B1
IC50C1
IC50D1
IC50E1
IC50F1
IC50G1
IC50H1
IC50J1
IC50K1
IC50L1
IC50M1
IC50N1
IC50P1
IC50Q1
IC50R1
IC50S1
IC50T1
IC50U1
IC50V1
IC50W1
IC50X1
IC50Y1
IC50Z1
IC51A1
IC51B1
IC51C1
IC51D1
IC51E1
IC51F1
IC51G1
IC51H1
IC51J1
IC51K1
IC51L1
IC51M1
IC51N1
IC51P1
IC51Q1
IC51R1
IC51S1
IC51T1
IC51U1
IC51V1
IC51W1
IC51X1
IC51Y1
IC51Z1
IC52A1
IC52B1
IC52C1
IC52D1
IC52E1
IC52F1
IC52G1
IC52H1
IC52J1
IC52K1
IC52L1
IC52M1
IC52N1
IC52P1
IC52Q1
IC52R1
IC52S1
IC52T1
IC52U1
IC52V1
IC52W1
IC52X1
IC52Y1
IC52Z1
IC53A1
IC53B1
IC53C1
IC53D1
IC53E1
IC53F1
IC53G1
IC53H1
IC53J1
IC53K1
IC53L1
IC53M1
IC53N1
IC53P1
IC53Q1
IC53R1
IC53S1
IC53T1
IC53U1
IC53V1
IC53W1
IC53X1
IC53Y1
IC53Z1
IC54A1
IC54B1
IC54C1
IC54D1
IC54E1
IC54F1
IC54G1
IC54H1
IC54J1
IC54K1
IC54L1
IC54M1
IC54N1
IC54P1
IC54Q1
IC54R1
IC54S1
IC54T1
IC54U1
IC54V1
IC54W1
IC54X1
IC54Y1
IC54Z1
IC55A1
IC55B1
IC55C1
IC55D1
IC55E1
IC55F1
IC55G1
IC55H1
IC55J1
IC55K1
IC55L1
IC55M1
IC55N1
IC55P1
IC55Q1
IC55R1
IC55S1
IC55T1
IC55U1
IC55V1
IC55W1
IC55X1
IC55Y1
IC55Z1
IC56A1
IC56B1
IC56C1
IC56D1
IC56E1
IC56F1
IC56G1
IC56H1
IC56J1
IC56K1
IC56L1
IC56M1
IC56N1
IC56P1
IC56Q1
IC56R1
IC56S1
IC56T1
IC56U1
IC56V1
IC56W1
IC56X1
IC56Y1
IC56Z1
IC57A1
IC57B1
IC57C1
IC57D1
IC57E1
IC57F1
IC57G1
IC57H1
IC57J1
IC57K1
IC57L1
IC57M1
IC57N1
IC57P1
IC57Q1
IC57R1
IC57S1
IC57T1
IC57U1
IC57V1
IC57W1
IC57X1
IC57Y1
IC57Z1
IC58A1
IC58B1
IC58C1
IC58D1
IC58E1
IC58F1
IC58G1
IC58H1
IC58J1
IC58K1
IC58L1
IC58M1
IC58N1
IC58P1
IC58Q1
IC58R1
IC58S1
IC58T1
IC58U1
IC58V1
IC58W1
IC58X1
IC58Y1
IC58Z1
IC59A1
IC59B1
IC59C1
IC59D1
IC59E1
IC59F1
IC59G1
IC59H1
IC59J1
IC59K1
IC59L1
IC59M1
IC59N1
IC59P1
IC59Q1
IC59R1
IC59S1
IC59T1
IC59U1
IC59V1
IC59W1
IC59X1
IC59Y1
IC59Z1
IC60A1
IC60B1
IC60C1
IC60D1
IC60E1
IC60F1
IC60G1
IC60H1
IC60J1
IC60K1
IC60L1
IC60M1
IC60N1
IC60P1
IC60Q1
IC60R1
IC60S1
IC60T1
IC60U1
IC60V1
IC60W1
IC60X1
IC60Y1
IC60Z1
IC61A1
IC61B1
IC61C1
IC61D1
IC61E1
IC61F1
IC61G1
IC61H1
IC61J1
IC61K1
IC61L1
IC61M1
IC61N1
IC61P1
IC61Q1
IC61R1
IC61S1
IC61T1
IC61U1
IC61V1
IC61W1
IC61X1
IC61Y1
IC61Z1
IC62A1
IC62B1
IC62C1
IC62D1
IC62E1
IC62F1
IC62G1
IC62H1
IC62J1
IC62K1
IC62L1
IC62M1
IC62N1
IC62P1
IC62Q1
IC62R1
IC62S1
IC62T1
IC62U1
IC62V1
IC62W1
IC62X1
IC62Y1
IC62Z1
IC63A1
IC63B1
IC63C1
IC63D1
IC63E1
IC63F1
IC63G1
IC63H1
IC63J1
IC63K1
IC63L1
IC63M1
IC63N1
IC63P1
IC63Q1
IC63R1
IC63S1
IC63T1
IC63U1
IC63V1
IC63W1
IC63X1
IC63Y1
IC63Z1
IC64A1
IC64B1
IC64C1
IC64D1
IC64E1
IC64F1
IC64G1
IC64H1
IC64J1
IC64K1
IC64L1
IC64M1
IC64N1
IC64P1
IC64Q1
IC64R1
IC64S1
IC64T1
IC64U1
IC64V1
IC64W1
IC64X1
IC64Y1
IC64Z1
IC65A1
IC65B1
IC65C1
IC65D1
IC65E1
IC65F1
IC65G1
IC65H1
IC65J1
IC65K1
IC65L1
IC65M1
IC65N1
IC65P1
IC65Q1
IC65R1
IC65S1
IC65T1
IC65U1
IC65V1
IC65W1
IC65X1
IC65Y1
IC65Z1
IC66A1
IC66B1
IC66C1
IC66D1
IC66E1
IC66F1
IC66G1
IC66H1
IC66J1
IC66K1
IC66L1
IC66M1
IC66N1
IC66P1
IC66Q1
IC66R1
IC66S1
IC66T1
IC66U1
IC66V1
IC66W1
IC66X1
IC66Y1
IC66Z1
IC67A1
IC67B1
IC67C1
IC67D1
IC67E1
IC67F1
IC67G1
IC67H1
IC67J1
IC67K1
IC67L1
IC67M1
IC67N1
IC67P1
IC67Q1
IC67R1
IC67S1
IC67T1
IC67U1
IC67V1
IC67W1
IC67X1
IC67Y1
IC67Z1
IC68A1
IC68B1
IC68C1
IC68D1
IC68E1
IC68F1
IC68G1
IC68H1
IC68J1
IC68K1
IC68L1
IC68M1
IC68N1
IC68P1
IC68Q1
IC68R1
IC68S1
IC68T1
IC68U1
IC68V1
IC68W1
IC68X1
IC68Y1
IC68Z1
IC69A1
IC69B1
IC69C1
IC69D1
IC69E1
IC69F1
IC69G1
IC69H1
IC69J1
IC69K1
IC69L1
IC69M1
IC69N1
IC69P1
IC69Q1
IC69R1
IC69S1
IC69T1
IC69U1
IC69V1
IC69W1
IC69X1
IC69Y1
IC69Z1
IC70A1
IC70B1
IC70C1
IC70D1
IC70E1
IC70F1
IC70G1
IC70H1
IC70J1
IC70K1
IC70L1
IC70M1
IC70N1
IC70P1
IC70Q1
IC70R1
IC70S1
IC70T1
IC70U1
IC70V1
IC70W1
IC70X1
IC70Y1
IC70Z1
IC71A1
IC71B1
IC71C1
IC71D1
IC71E1
IC71F1
IC71G1
IC71H1
IC71J1
IC71K1
IC71L1
IC71M1
IC71N1
IC71P1
IC71Q1
IC71R1
IC71S1
IC71T1
IC71U1
IC71V1
IC71W1
IC71X1
IC71Y1
IC71Z1
IC72A1
IC72B1
IC72C1
IC72D1
IC72E1
IC72F1
IC72G1
IC72H1
IC72J1
IC72K1
IC72L1
IC72M1
IC72N1
IC72P1
IC72Q1
IC72R1
IC72S1
IC72T1
IC72U1
IC72V1
IC72W1
IC72X1
IC72Y1
IC72Z1
IC73A1
IC73B1
IC73C1
IC73D1
IC73E1
IC73F1
IC73G1
IC73H1
IC73J1
IC73K1
IC73L1
IC73M1
IC73N1
IC73P1
IC73Q1
IC73R1
IC73S1
IC73T1
IC73U1
IC73V1
IC73W1
IC73X1
IC73Y1
IC73Z1
IC74A1
IC74B1
IC74C1
IC74D1
IC74E1
IC74F1
IC74G1
IC74H1
IC74J1
IC74K1
IC74L1
IC74M1
IC74N1
IC74P1
IC74Q1
IC74R1
IC74S1
IC74T1
IC74U1
IC74V1
IC74W1
IC74X1
IC74Y1
IC74Z1
IC75A1
IC75B1
IC75C1
IC75D1
IC75E1
IC75F1
IC75G1
IC75H1
IC75J1
IC75K1
IC75L1
IC75M1
IC75N1
IC75P1
IC75Q1
IC75R1
IC75S1
IC75T1
IC75U1
IC75V1
IC75W1
IC75X1
IC75Y1
IC75Z1
IC76A1
IC76B1
IC76C1
IC76D1
IC76E1
IC76F1
IC76G1
IC76H1
IC76J1
IC76K1
IC76L1
IC76M1
IC76N1
IC76P1
IC76Q1
IC76R1
IC76S1
IC76T1
IC76U1
IC76V1
IC76W1
IC76X1
IC76Y1
IC76Z1
IC77A1
IC77B1
IC77C1
IC77D1
IC77E1
IC77F1
IC77G1
IC77H1
IC77J1
IC77K1
IC77L1
IC77M1
IC77N1
IC77P1
IC77Q1
IC77R1
IC77S1
IC77T1
IC77U1
IC77V1
IC77W1
IC77X1
IC77Y1
IC77Z1
IC78A1
IC78B1
IC78C1
IC78D1
IC78E1
IC78F1
IC78G1
IC78H1
IC78J1
IC78K1
IC78L1
IC78M1
IC78N1
IC78P1
IC78Q1
IC78R1
IC78S1
IC78T1
IC78U1
IC78V1
IC78W1
IC78X1
IC78Y1
IC78Z1
IC79A1
IC79B1
IC79C1
IC79D1
IC79E1
IC79F1
IC79G1
IC79H1
IC79J1
IC79K1
IC79L1
IC79M1
IC79N1
IC79P1
IC79Q1
IC79R1
IC79S1
IC79T1
IC79U1
IC79V1
IC79W1
IC79X1
IC79Y1
IC79Z1
IC80A1
IC80B1
IC80C1
IC80D1
IC80E1
IC80F1
IC80G1
IC80H1
IC80J1
IC80K1
IC80L1
IC80M1
IC80N1
IC80P1
IC80Q1
IC80R1
IC80S1
IC80T1
IC80U1
IC80V1
IC80W1
IC80X1
IC80Y1
IC80Z1
IC81A1
IC81B1
IC81C1
IC81D1
IC81E1
IC81F1
IC81G1
IC81H1
IC81J1
IC81K1
IC81L1
IC81M1
IC81N1
IC81P1
IC81Q1
IC81R1
IC81S1
IC81T1
IC81U1
IC81V1
IC81W1
IC81X1
IC81Y1
IC81Z1
IC82A1
IC82B1
IC82C1
IC82D1
IC82E1
IC82F1
IC82G1
IC82H1
IC82J1
IC82K1
IC82L1
IC82M1
IC82N1
IC82P1
IC82Q1
IC82R1
IC82S1
IC82T1
IC82U1
IC82V1
IC82W1
IC82X1
IC82Y1
IC82Z1
IC83A1
IC83B1
IC83C1
IC83D1
IC83E1
IC83F1
IC83G1
IC83H1
IC83J1
IC83K1
IC83L1
IC83M1
IC83N1
IC83P1
IC83Q1
IC83R1
IC83S1
IC83T1
IC83U1
IC83V1
IC83W1
IC83X1
IC83Y1
IC83Z1
IC84A1
IC84B1
IC84C1
IC84D1
IC84E1
IC84F1
IC84G1
IC84H1
IC84J1
IC84K1
IC84L1
IC84M1
IC84N1
IC84P1
IC84Q1
IC84R1
IC84S1
IC84T1
IC84U1
IC84V1
IC84W1
IC84X1
IC84Y1
IC84Z1
IC85A1
IC85B1
IC85C1
IC85D1
IC85E1
IC85F1
IC85G1
IC85H1
IC85J1
IC85K1
IC85L1
IC85M1
IC85N1
IC85P1
IC85Q1
IC85R1
IC85S1
IC85T1
IC85U1
IC85V1
IC85W1
IC85X1
IC85Y1
IC85Z1
IC86A1
IC86B1
IC86C1
IC86D1
IC86E1
IC86F1
IC86G1
IC86H1
IC86J1
IC86K1
IC86L1
IC86M1
IC86N1
IC86P1
IC86Q1
IC86R1
IC86S1
IC86T1
IC86U1
IC86V1
IC86W1
IC86X1
IC86Y1
IC86Z1
IC87A1
IC87B1
IC87C1
IC87D1
IC87E1
IC87F1
IC87G1
IC87H1
IC87J1
IC87K1
IC87L1
IC87M1
IC87N1
IC87P1
IC87Q1
IC87R1
IC87S1
IC87T1
IC87U1
IC87V1
IC87W1
IC87X1
IC87Y1
IC87Z1
IC88A1
IC88B1
IC88C1
IC88D1
IC88E1
IC88F1
IC88G1
IC88H1
IC88J1
IC88K1
IC88L1
IC88M1
IC88N1
IC88P1
IC88Q1
IC88R1
IC88S1
IC88T1
IC88U1
IC88V1
IC88W1
IC88X1
IC88Y1
IC88Z1
IC89A1
IC89B1
IC89C1
IC89D1
IC89E1
IC89F1
IC89G1
IC89H1
IC89J1
IC89K1
IC89L1
IC89M1
IC89N1
IC89P1
IC89Q1
IC89R1
IC89S1
IC89T1
IC89U1
IC89V1
IC89W1
IC89X1
IC89Y1
IC89Z1
IC90A1
IC90B1
IC90C1
IC90D1
IC90E1
IC90F1
IC90G1
IC90H1
IC90J1
IC90K1
IC90L1
IC90M1
IC90N1
IC90P1
IC90Q1
IC90R1
IC90S1
IC90T1
IC90U1
IC90V1
IC90W1
IC90X1
IC90Y1
IC90Z1
IC91A1
IC91B1
IC91C1
IC91D1
IC91E1
IC91F1
IC91G1
IC91H1
IC91J1
IC91K1
IC91L1
IC91M1
IC91N1
IC91P1
IC91Q1
IC91R1
IC91S1
IC91T1
IC91U1
IC91V1
IC91W1
IC91X1
IC91Y1
IC91Z1
IC92A1
IC92B1
IC92C1
IC92D1
IC92E1
IC92F1
IC92G1
IC92H1
IC92J1
IC92K1
IC92L1
IC92M1
IC92N1
IC92P1
IC92Q1
IC92R1
IC92S1
IC92T1
IC92U1
IC92V1
IC92W1
IC92X1
IC92Y1
IC92Z1
IC93A1
IC93B1
IC93C1
IC93D1
IC93E1
IC93F1
IC93G1
IC93H1
IC93J1
IC93K1
IC93L1
IC93M1
IC93N1
IC93P1
IC93Q1
IC93R1
IC93S1
IC93T1
IC93U1
IC93V1
IC93W1
IC93X1
IC93Y1
IC93Z1
IC94A1
IC94B1
IC94C1
IC94D1
IC94E1
IC94F1
IC94G1
IC94H1
IC94J1
IC94K1
IC94L1
IC94M1
IC94N1
IC94P1
IC94Q1
IC94R1
IC94S1
IC94T1
IC94U1
IC94V1
IC94W1
IC94X1
IC94Y1
IC94Z1
IC95A1
IC95B1
IC95C1
IC95D1
IC95E1
IC95F1
IC95G1
IC95H1
IC95J1
IC95K1
IC95L1
IC95M1
IC95N1
IC95P1
IC95Q1
IC95R1
IC95S1
IC95T1
IC95U1
IC95V1
IC95W1
IC95X1
IC95Y1
IC95Z1
IC96A1
IC96B1
IC96C1
IC96D1
IC96E1
IC96F1
IC96G1
IC96H1
IC96J1
IC96K1
IC96L1
IC96M1
IC96N1
IC96P1
IC96Q1
IC96R1
IC96S1
IC96T1
IC96U1
IC96V1
IC96W1
IC96X1
IC96Y1
IC96Z1
IC97A1
IC97B1
IC97C1
IC97D1
IC97E1
IC97F1
IC97G1
IC97H1
IC97J1
IC97K1
IC97L1
IC97M1
IC97N1
IC97P1
IC97Q1
IC97R1
IC97S1
IC97T1
IC97U1
IC97V1
IC97W1
IC97X1
IC97Y1
IC97Z1
IC98A1
IC98B1
IC98C1
IC98D1
IC98E1
IC98F1
IC98G1
IC98H1
IC98J1
IC98K1
IC98L1
IC98M1
IC98N1
IC98P1
IC98Q1
IC98R1
IC98S1
IC98T1
IC98U1
IC98V1
IC98W1
IC98X1
IC98Y1
IC98Z1
IC99A1
IC99B1
IC99C1
IC99D1
IC99E1
IC99F1
IC99G1
IC99H1
IC99J1
IC99K1
IC99L1
IC99M1
IC99N1
IC99P1
IC99Q1
IC99R1
IC99S1
IC99T1
IC99U1
IC99V1
IC99W1
IC99X1
IC99Y1
IC99Z1
POWER
DEFL
LIVE
BY
DV
AP
AQ
AR
AS
AT
AU
AV
AW
AX
AY
AZ
BA
BB
BC
BD
BE
BF
BG
BH
BJ
BK
BL
BM
BN
BP
BQ
BR
BS
BT
BU
BV
BW
BX
BY
BZ
CA
CB
CC
CD
CE
CF
CG
CH
CJ
CK
CL
CM
CN
CP
CQ
CR
CS
CT
CU
CV
CW
CX
CY
CZ
DA
DB
DC
DD
DE
DF
DG
DH
DJ
DK
DL
DM
DN
DP
DQ
DR
DS
DT
DU
DV
DW
DX
DY
DZ
EA
EB
EC
ED
EE
EF
EG
EH
EJ
EK
EL
EM
EN
EP
EQ
ER
ES
ET
EU
EV
EW
EX
EY
EZ
FA
FB
FC
FD
FE
FF
FG
FH
FJ
FK
FL
FM
FN
FP
FQ
FR
FS
FT
FU
FV
FW
FX
FY
FZ
GA
GB
GC
GD
GE
GF
GG
GH
GJ
GK
GL
GM
GN
GP
GQ
GR
GS
GT
GU
GV
GW
GX
GY
GZ
HA
HB
HC
HD
HE
HF
HG
HH
HJ
HK
HL
HM
HN
HP
HQ
HR
HS
HT
HU
HV
HW
HX
HY
HZ
JA
JB
JC
JD
JE
JF
JG
JH
JJ
JK
JL
JM
JN
JP
JQ
JR
JS
JT
JU
JV
JW
JX
JY
JZ
KA
KB
KC
KD
KE
KF
KG
KH
KJ
KK
KL
KM
KN
KP
KQ
KR
KS
KT
KU
KV
KW
KX
KY
KZ
LA
LB
LC
LD
LE
LF
LG
LH
LJ
LK
LL
LM
LN
LP
LQ
LR
LS
LT
LU
LV
LW
LX
LY
LZ
MA
MB
MC
MD
ME
MF
MG
MH
MJ
MK
ML
MM
MN
MP
MQ
MR
MS
MT
MU
MV
MW
MX
MY
MZ
NA
NB
NC
ND
NE
NF
NG
NH
NJ
NK
NL
NM
NN
NP
NQ
NR
NS
NT
NU
NV
NW
NX
NY
NZ
PA
PB
PC
PD
PE
PF
PG
PH
PJ
PK
PL
PM
PN
PP
PQ
PR
PS
PT
PU
PV
PW
PX
PY
PZ
QA
QB
QC
QD
QE
QF
QG
QH
QJ
QK
QL
QM
QN
QP
QQ
QR
QS
QT
QU
QV
QW
QX
QY
QZ
RA
RB
RC
RD
RE
RF
RG
RH
RJ
RK
RL
RM
RN
RP
RQ
RR
RS
RT
RU
RV
RW
RX
RY
RZ
SA
SB
SC
SD
SE
SF
SG
SH
SJ
SK
SL
SM
SN
SP
SQ
SR
SS
ST
SU
SV
SW
SX
SY
SZ
TA
TB
TC
TD
TE
TF
TG
TH
TJ
TK
TL
TM
TN
TP
TQ
TR
TS
TT
TU
TV
TW
TX
TY
TZ
UA
UB
UC
UD
UE
UF
UG
UH
UJ
UK
UL
UM
UN
UP
UQ
UR
US
UT
UU
UV
UW
UX
UY
UZ
VA
VB
VC
VD
VE
VF
VG
VH
VJ
VK
VL
VM
VN
VP
VQ
VR
VS
VT
VU
VV
VW
VX
VY
VZ
WA
WB
WC
WD
WE
WF
WG
WH
WJ
WK
WL
WM
WN
WP
WQ
WR
WS
WT
WU
WV
WW
WX
WY
WZ
XA
XB
XC
XD
XE
XF
XG
XH
XJ
XK
XL
XM
XN
XP
XQ
XR
XS
XT
XU
XV
XW
XX
XY
XZ
YA
YB
YC
YD
YE
YF
YG
YH
YJ
YK
YL
YM
YN
YP
YQ
YR
YS
YT
YU
YV
YW
YX
YY
YZ
ZA
ZB
ZC
ZD
ZE
ZF
ZG
ZH
ZJ
ZK
ZL
ZM
ZN
ZP
ZQ
ZR
ZS
ZT
ZU
ZV
ZW
ZX
ZY
ZZ
J 240A77301
CMK-140X-PA▲
PCB MBC DEFL


1
2
3
4
5
A
B
C
IC7005
IC7006
IC7007
IC7008
IC7002
IC7003
IC7009
IC7010
IC7011
IC7401
IC7004
PIP
VR7001
SUB-TINT
VR7002
LEVEL-ADJ
DL PHASE
R-Y DEM
B-Y DEM
PAL VCO
NTSC VCO
SECAM ID
BELL FILTER
CMK-140X
240A79301

PCB PIP


1
2
3
4
A
B
C
IC6003
IC6001
IC6004
IC6012
IC6010
DCF
CMK-140X
210B25801

PCB DCF


1
2
3
4
A
B
C
PCC/DBF
DV
DF
CX
CAUTION
HIGH-VOLTAGE
PCC-PHASE
PCC-AMP
H-WIDTH
Q5003
Q5002
Q5001
IC5001
Q5503
Q5504
Q5502
Q5006
Q5004
Q5005
T5501
D5502
R5518
R5516
R5517
R5519
R5513
R5514
R5515
C5507
C5506
SOC 2000mA Z5001
PZ1
PZ2
PZ3
210B25501

PCB PCC/DBF


1
2
3
4
A
B
C
CT
210B25301
R-DRIVE
B-DRIVE
R-SCR
G-SCR
B-SCR
CRT
G-OUT
R-OUT
B-OUT
PS
F1
F2
SA
SVM
CMK-140X
PA
CB
CC
CA
CK
AK

PCB VMCRT


1
2
3
A
B
C
IC3008
IC3007
IC3006
IC3003
IC3004
IC3005
IC3015
IC3001
IC3009
SD
SN
NZ
AU2
LD2
NICAM
210B31801
CMK-140X-BU
to G20

PCB-NICAM



PCB SWIFT TEXT



PCB TERMINAL



PCB AV-SW

8 9 10 11 12 13 14 15 16

⚠ PCB-DCF




7.7V
7.2V
7.2V
0V
9.8V
3.3V
3.3V
6.8V
12.4V
C6035
25V
10μ
DF6002
D.F
0.13mH
VR6004
B-1K
PHASE-2
C6037
Z-.01
C6036
Z-.01
R6019
330
7.8V
7.2V
7.2V
0V
R6022
10K
C6042
Z-.01
3.2V
3.2V
6.7V
12.4V
C6041
Z-.01
VR6006
B-1K
PHASE-3
C6043
Z-.01
TP-2
TP-3
TP-5
R6023
100
R6024
100
R6025
100
C6044
16V
47μ
0V
12.4V
6.7V
6.7V
6.7V
V-APA
H CORRELATION
V CORRELATION
V-APACON
LF6003
HS149HIS-2433WAD
B.P.F
4.4MHz
.35V
R6026
4.7K
6.5V
C6045
Z-.01
R6027
1K
C6046
Z-.01
0.8Vp-p(H)
0.7Vp-p(H)
1Vp-p(H)
IC6011 KIC-SUB Y/C SEPARATOR
6V
0V
2.7V
2.7V
2.4V
3V
12.4V
12.4V
R6028
2.2K
R6029
2.2K
VR6007
B-1K
PHASE-4
VR6008
B-2K
LEVEL-4
C6048
16V
47μ
C6047
16V
47μ
TP-6
12.4V
Q5008
JC501-Q.R
.6V
0V
R6040
4.7K
R6042
4.1K
R6045
10K
R6043
10K
R6041
2.2K
Q6011
JA101-Q.R
Q6010
JC501-Q.R
Q6009
JC501-Q.R
R6046
10K
R6039
1K
AY
PCB-AV AY
AL
PCB-AV AL


PCB-AV
PCB-CONTROL
PCB-EPJ
PCB-DEFL/REG
IC302
STK4132MKII
AUDIO AMP
IP101
VIF PACK
TU101
IC101
MPC78M09H
9V REG
IC202
TEA5114A
RGB-SW1
IC203
TEA5114A
RGB-SW2
IC204
TEA5114A
RGB-SW3
IC601
TDA4565
CTI
IC201
TA8659A
VCJ
IC205
MC14551BCP
VIDEO-SW
Q301
JC501-Q,R
RELAY-SW3
Q302
JC501-Q,R
RELAY-SW2
Q303
JA101-Q,R
RELAY-SW1
Q304
JC501-Q,R
MUTE-SW1
Q305
JC501-Q,R
MUTE-SW2
Q101
JC501-Q,R
SENSE SW
Q217
JA101-Q,R
VIDEO-BUFFER
Q211
JC501-Q,R
VIDEO-BUFFER2
Q213
JC501-Q,R
Y-BUFFER3
Q207
JC501-Q,R
Y-AMP3
Q219
JA101-Q,R
Y-AMP1
Q201
2SC2058S-Q
Y-AMP2
Q221
JA101-Q,R
BLK-AMP1
Q222
2SD1820
BLK-AMP2
Q209
Q604
Q208
AR
AS
AT
AU
AV
SC
EP
PF
NA
CHILD-H
MUTE1
WIDE
BAL
VOL
L-IN
R-IN
B
A
R-OUT
GND
L-OUT
N.C
GRAEQ-DA
GRAEQ-CL
SP-R
SP-L
SWIT CHED
SW-C1
SW-C2
VIDEO-IN
VIDEO-OUT
CHROMA
+12
SYNC
PERI-1-H
PERI-2-H
L-OUT
GND
R-OUT
GND
L-IN
GND


6
7
8
9
10
11
PCB-TERMINAL
PCB-YUV
PCB-DEFL/REG
PCB-PIP
L-OUT
GND
R-OUT
L-IN
R-IN
MUTE2
NICAM-IF
+12V
+5V
NICAM-L
MUTED
ST
MONO1
MONO2
SEL1
SEL2
B-Y IN
B-Y OUT
R-Y IN
R-Y OUT
Y IN
YOUT
PICT OUT
BLUE BACK IN OUT
BLUE
FBP
BLK IN
VIDEO
B
G
R
BLK
H-SYNC
IC301
TC40538P
/HEF40538P
AUDIO-SW
IP102 SIF PACK
Q224
JA101-Q,R
SYNC-BUFFER
IC702 M50554-185SP
Q713
JC501-Q,R
BLK-BUFFER
Q223
JA101-Q,R
BLK-AMP3
Q221
JA101-Q,R
BLK-AMP1
Q222
2SC2058S-Q
BLK-AMP2
Q218
JA101-Q,R
SYNC-AMP2
Q216
JC501-Q,R
SYNC-AMP1
IC307
TC40538P
/HEF40538P
SYNC-SW
IC204
TEA5114A
RGB-SW3
Q219
JA101-Q,R
Y-AMP1
Q201
2SC2058S-Q
/2SC3724-E
Y-AMP2
Q203
JC501-Q,R
DELAY-SW1
Q202
JC501-Q,R
DELAY-SW2
IC705
MM1280-M
RESET
Q507
JC501-Q,R
H-PHASE-SW1
IC706
PD6326C
D/A
CONVERTER
Q204
JC501-Q,R
PICTURE-MUTE
Q501
JC501-Q,R
AFC-SW
0-POSI-L
50Hz-H
Q502
JC501-Q,R
H-PHASE-SW2
IC201 TA8659AN
VCJ
Q503
JA101-Q,R
50/60HZ-SW1
Q220
JA101-Q,R


PCB-TERMINAL
PCB-YUV
PCB-PIP
IC301
TC4053BP
/HEF4053BP
AUDIO-SW
IC712
HEF4053BP
MPX-MODE-SW
IP102 SIF PACK
Q224
JA101-Q,R
SYNC-BUFFER
IC702 M50554-185SP CHARA-GENE
Q713
JC501-Q,R
BLK-BUFFER
Q223
JA101-Q,R
BLK-AMP3
Q218
JA101-Q,R
SYNC-AMP2
Q221
JA101-Q,R
BLK-AMP1
Q222
2SC2058S-Q
BLK-AMP2
Q215
JC501-Q,R
SYNC-AMP1
IC207
TC4053BP
/HEF4053BP
SYNC-SW
IC204
TEA5114A
RGB-SW3
Q219
JA101-Q,R
Y-AMP1
Q201
2SC2058S-Q
2SC2724-L
Y-AMP2
Q203
JC501-Q,R
DELAY-SW1
Q202
JC501-Q,R
DELAY-SW2
Q507
JC501-Q,R
H-PHASE-SW1
Q204
JC501-Q,R
PICTURE-MUTE
Q501
JC501-Q,R
AFC-SW
Q502
JC501-Q,R
H-PHASE-SW2
Q503
JA101-Q,R
50/60HZ-SW1
Q220
JA101-Q,R
IC705
MN1280-M
RESET
IC706
PD6326C
A/A
CONVERTER
IC201
TA8659AN
VCJ

PCB-SWIFTEXT

SCHEMATIC DIAGRAM MODEL:CT-37C2EDT



SERVICING PRECAUTION

SYMBOLS INDICATE COMPONENTS HAVING SPECIAL CHARACTERISTICS IMPORTANT TO SAFETY AND PERFORMANCE. THERFORE REPLACEMENT OF ANY SAFETY PARTS SHOULD BE IDENTICAL IN VALUE AND CHARACTERISTICS. FOR ACCURACY OF THE REPLACEMENT REFER TO THE PARTS LIST OF SERVICE MANUAL.

DON'T DEGRADE THE SAFETY OF THE RECEIVERS THROUGH IMPROPER SERVICING.

NOTE 1:

1. The unit of resistance is "ohm" with no symbol.
   Accordingly, K = 1000 ohms
   M = 1000K ohms.
2. The wattage of resistors, if not specifically designated, is less than 1/4 watt.
3. Resistors, if not specifically designated, are carbon resistors.
4. The marks of resistors are as follows:
   - (CE) : Cemented resistor
   - (MB) : Metal oxide film resistor (type B)
   - (MPC) : Metal plate cement resistor.
   - (ML) : Metal linear resistor.
   - (S) : Fixed composition resistor
   - (W) : Wire wound resistor
   - (M) : Metal film resistor
5. The tolerance of resistor value, if not specifically designated, is: ±5%, K = ±10% M = ±20%
6. The unit of capacitance, if not specifically designated, is:
   a) μF, for numbers less than 1
   b) PF, for numbers more than 1
7. Capacitors, if not specifically designated are Ceramic capacitors except electrolytic capacitors.
8. The marks of capacitors are as follows:
   - (ALM) : Aluminus electrolytic capacitor
   - (MF) : Polyester capacitor
   - (PP) : Polypropylene film capacitor
   - (TANT) : Tantalum capacitor
   - (TF) : Twin film capacitor.
   - (MF PP) : Polyester polypropylene film capacitor.
   - (MPP) : Metallize plastic film capacitor.
   - (NP) : Non polarized electrolytic capacitor.
   - (PS) : Styrol capacitor.
   - (SC) : Semi conductor capacitor.
   - (+) : Electrolytic capacitor
9. The DC working voltage of capacitor, if not specifically designated is: 50V
10. The tolerance of capacitor value, if not specifically designated is:
    ±10% for polyester capacitor
    ±5% for ceramic capacitor
    and J = ±5% K = ±10% M = ±20% P = +100% 0% Z = +80% −20%
    C = ±0.25PF D = ±0.5PF F = ±1PF N = ±30%

SPECIFIC SYMBOL

Zener Diode	Varistor
Varicap	Crystal unit
Posistor	Air Gap
Thermistor	Part (resistor) attached on the copper-foil side of PCB
Fusible Resistor	Ceramic filter

NOTE 2:

1. DC voltages were measured from points indicated to the circuit ground with a high-Z voltmeter.
2. Waveforms were taken with offset PAL colour bar signal.


Q101
JC501-Q.R
SENSE SW
Q217
JA101-Q.R
VIDEO-BUFFER
IC202
TEA5114A
RGB-SW1
IC203
TEA5114A
RGB-SW2
Q221
JA101-Q.R
BLK-AMP1
IC204
TEA5114A
RGB-SW3
Q211
JC501-Q.R
VIDEO-BUFFER2
Q213
JC501-Q.R
Y-BUFFER3
IC601
TDA4565
CT1
Q219
JA101-Q.R
Y-AMP1
Q201
2SC2058S
2SC2724
Y-AMP2
IC205
MC14551BCP
VIDEO-SW
Q207
JC501-Q.R
Y-AMP3
Q208
JA101-Q.R
Y-AMP4
IC201
TA8659AN
VCJ
Q209
JC501-Q.R
Y-BUFFER1
Q604
JC501-Q.R
C-BUFFER1
Q210
JA101-Q.R
Y-BUFFER2
Q608
JC501-Q.R
C-BUFFER2
Q503
JC501-Q.R
TEMP-SW1
Q502
JC501-Q.R
TEMP-SW2
Q507
JC501-Q.R
TEMP-SW3
N.C
R-OUT
GND
L-OUT
SWIT CHED
Y
SW-C1
SW-C2
VIDEO-OUT
CHROMA
+12
SYNC
PERI-1-H
PERI-2-H
B
G
R
BLK
SW3
SW2
SW1
FP
CC
CB
CT
PCB-PIP
PCB-VMCRT
IC601 TDA4565
THRESHOLD SWITCH
CLAMPING CIRCUIT
6X 90ns 3X 90ns 45ns
GYRATOR DELAY CELLS
DIFFERENTIATING STAGE
INTEGRATOR STAGE PULSEFORMER
SWITCHING AND STORAGE STAGE
CHASSIS WAVEFORMS
①0.2Vp-p(H)
②4Vp-p(V)
③5.2Vp-p(H)
④1Vp-p(H)
⑤0.9Vp-p(H)
⑧5Vp-p(H)
⑨4.8Vp-p(H)
⑩0.9Vp-p(H)
⑪1.9Vp-p(H)
⑫0.9Vp-p(H)





IC701 μPD75116CW



④1Vp-p(H)

⑤0.9Vp-p(H)

⑥0.7Vp-p(H)

⑦5Vp-p(H)

⑪1.9Vp-p(H)

⑫0.9Vp-p(H)

⑬0.9Vp-p(H)


⑭0.9Vp-p(H)


Q223 JA101-Q,R BLK-AMP3
Q221 JA101-Q,R BLK-AMP1
Q222 2SC2058S-Q BLK-AMP2
Q218 JA101-Q,R SYNC-AMP2
Q216 JC501-Q,R SYNC-AMP1
IC207 TC40538P /HEF40538P SYNC-SW
IC204 TEA5114A RGB-SW3
Q219 JA101-Q,R Y-AMP1
Q201 2SC2058S-Q 2SK2724-E Y-AMP2
Q203 JC501-Q,R DELAY-SW1
Q202 JC501-Q,R DELAY-SW2
IC705 MN1280-M MICRO-RESET
IC706 PD6326C D/A CONVERTER
Q507 JC501-Q,R H-PHASE-SW1
Q204 JC501-Q,R PICTURE-MUTE
IC201 TA8658AN VCJ
Q501 JC501-Q,R AFC-SW
Q502 JC501-Q,R H-PHASE-SW2
Q503 JA101-Q,R 50/60HZ-SW1
Q506 JA101-Q,R 50/60HZ-SW2
Q220 JA101-Q,R BLK-BUFFER
Q504 JC501-Q,R H-SYNC-INV
Q714 JA101-Q,R C-SYSTEM-SW1
Q715 JA101-Q,R C-SYSTEM-SW2
Q716 JA101-Q,R C-SYSTEM-SW3
Q501 JC501-Q,R BAND-PASS-SW
Q505 JC501-Q,R V-SYNC-INV
Q719 JC501-Q,R 50/60HZ SW3
Q508 JC501-Q,R H-PHASE-SW3
TEMP1
TEMP2
J502 JC501-Q,R TEMP-SW2
Q506 JC501-Q,R DCF-MUTE
Q605 JC501-Q,R SECAM-SW
CONTRAST
H-OUT
FBP
V-OUT
+12
N.C.
V-SYNC
PB
PCB-OEFL/REG
TE
PCB-SWIFTEXT
PD
PCB-OEFL/REG
DA
PCB-DCF
IC701 μPD75116CW
⑤0.9Vp-p(H)
⑥0.7Vp-p(H)
⑦5Vp-p(H)
⑫0.9Vp-p(H)
⑬0.9Vp-p(H)
⑭0.9Vp-p(H)









NOTE 1:

1. The unit of resistance is "ohm" with no symbol. Accordingly, K = 1000 ohms, M = 1000K ohms.
2. The wattage of resistors, if not specifically design than 1/4 watt.
3. Resistors, if not specifically designated, are carbon re
4. The marks of resistors are as follows:
   - (CE) : Cemented resistor
   - (MB) : Metal oxide film resistor (type B)
   - (MPC) : Metel plate cement resistor.
   - (ML) : Metal linear resistor.
   - (S) : Fixed composition resistor
   - (W) : Wire wound resistor
   - (M) : Metal film resistor
5. The tolerance of resistor value, if not specifically desi ±5%, K = ±10% M = ±20%
6. The unit of capacitance, if not specifically designated a) μF, for numbers less than 1 b) PF, for numbers more than 1
7. Capacitors, if not specifically designated are Ceramic except electrolytic capacitors.
8. The marks of capacitors are as follows:
   - (ALM) : Aluminus electrolytic capacitor
   - (MF) : Polyester capacitor
   - (PP) : Polypropylene film capacitor
   - (TANT) : Tantalum capacitor
   - (TF) : Twin film capacitor.
   - (MF.PP) : Polyester polypropylene film capacitor.
   - (MPP) : Metallize plastic film capacitor.
   - (NP) : Non polarized electrolytic capacitor.
   - (PS) : Styrol capacitor.
   - (SC) : Semi conductor capacitor.
   - (⫩) : Electrolytic capacitor
9. The DC working voltage of capacitor. if not specificall ed is: 50V
10. The tolerance of capacitor value, if not specifically des ±10% for polyester capacitor ±5% for ceramic capacitor and J = ±5% K= ±10% M = ±20% P = +100 0 C=±0.25PF D=±0.5PF F=±1PF Z=+80% -20%

SPECIFIC SYMBOL

Zener Diode		Varistor	
Varicap		Crystal unit	
Posistor		Air Gap	
Thermistor		Part (resistor) att on the copper-fo of PCB	
Fusible Resistor		Ceramic filter	

NOTE 2:

1. DC voltages were measured from points indicated to t ground with a high-Z voltmeter.
2. Waveforms were taken with offset PAL colour bar signal
3. This is a basic schematic diagram. Some sets may be s modification according to engineering improvement.

Printed i


PCB-DCF
AK
VIDEO OUT
C-IN
Y-IN
Q6A1
JC501-Q.R
C-BUFFER
Q2A2
JC501-Q.R
Y-BUFFER
Q2B7
JA101-Q.R
VIDEO-AMP-1
Q2A3
2SC2058S-Q
VIDEO-AMP-2
Q2B3
2SC2058S-Q
/2SC2724
VIDEO-BUFFE
PCB-DCF
AY
PCB-DCF
AL
BLK
FAST-SW
PERI-2-H
PERI-1-H
Q3A4
JC501-Q.R
AUDIO-BUFFER 2
Q3A5
JC501-Q.R
AUDIO-BUFFER 1
IC2A3
M51320P
AV2-OUT-SW


5
6
7
8
9
10
PCB-OCF
PCB-YCSW
PCB-YCSW
C-IN
Y-IN
A-IN
L-IN
R-OUT
L-OUT
C-OUT
IC2A1 LA7952 VIDEO-SW1
Q2A4 JC501-Q.R VIDEO-BUFFER-1
Q2B3 2SC2058S-Q /2SC2724 VIDEO-BUFFER-2
Q2B8 JA101-Q.R TRAP-OFF-SW2
Q2B9 JC501-Q.R TRAP-OFF-SW3
Q2A5 JC501-Q.R VIDEO BUFFER-3
Q2C0 JC501-Q.R Y-BUFFER-2
Q2A6 JC501-Q.R 3.58 SW1
Q2A8 JC501-Q.R 4.28 SW1
Q2A9 JC501-Q.R 4.43 SW
Q2B5 JC501-Q.R 4.28 SW2
Q2A7 JC501-Q.R 3.58 SW2
Q2B2 JC501-Q.R TRAP-OFF-SW1
Q3A3 JA101-Q.R VOL-CONT-BUFFER
IC3A1 LA7953 AUDIO-CONTROL
IC3A5 TC4053BP /HEF4053BP AUDIO-SW
IC3A3 BX7601A
Q3A2 2SC2236-Q, Y 12V-REG


6
7
8
9
10
11
PCB-YCSW
AF
AN
AM
AE
Y-IN
R-IN
L-IN
R-OUT
L-OUT
C-OUT
J3A1
L-MONO
PHONO-TERM
J2A3
S-TERM
IC2A1 LA7952 VIDEO-SW1
Q2A4
JC501-Q.R
VIDEO-BUFFER-1
Q2B8
YA101-Q.R
Q2B9
JC501-Q.R
TRAP-OFF-SW3
Q2C0
JC501-Q.R
Y-BUFFER-2
Q2A5
JC501-Q.R
VIDEO
BUFFER-3
Q2B3
2SC2058S-Q
/2SC2724
VIDEO-BUFFER-2
Q2A5
JC501-Q.R
3.58 SW1
Q2A8
JC501-Q.R
4.28 SW1
Q2A9
JC501-Q.R
4.43 SW
Q2B6
JC501-Q.R
4.28 SW2
Q2A7
JC501-Q.R
3.58 SW2
Q2B2
JC501-Q.R
TRAP-OFF-SW1
IC2A2
MS1321P
VIDEO-S
Q3A3
JA101-Q.R
VOL-CONT-BUFFER
IC3A1
LA7953
AUDIO-CONTROL
IC3A5
TC40S388P
/HEF40538BP
AUDIO-SW
IC3A3 BX7601A
Q3A2
2SC2236-O.Y
12V-REG


11
12
13
14
15
16
PCB-YCSW
AC
AD
C-OUT
Y-OUT
C-IN
Y-IN
PCB-AV
PCB-SIGNAL
CHILD-H
MUTE
WIDE
BAL
VOL
L-IN
R-IN
B
A
R-OUT
L-OUT
N. C.
GRAEQ. DA
GRAEQ. CL
SP-R
SP-L
SW-C2
SWITCHED-H
Y
SW-C1
VIDEO-IN
CHROMA
+12
SYNC
PERI-1-H
PERI-2-H
G
R
BLK
#21
Q2B4
2SD1-Q.R
C1-SW
Q2B5
2SD1-Q.R
C2-SW
Q2B0
JA101-Q.R
Y-BUFFER-1
Q5A3
JA101-Q.R
C-BUFFER-2
IC2A2
M51321P
VIDEO-SW2
IC3A2
LC7523
GEQ.L
SYNC
CHROMA
RESISTOR NETWORK
ANALOG SW
CONTROL
LATCH


PCB-DCF
AV
PCB-DCF
AL
FAST-SW
BLK
R
G
B
PERI-2-H
PERI-1-H
Q2B7
JA101-Q,R
VIDEO-AMP-1
Q2A3
2SC2058S-Q
VIDEO-AMP-2
Q2B3
2SC2058S-Q
2SC2724
VIDEO-BUFFE
Q3A4
JC501-Q,R
AUDIO-BUFFER 2
Q3A5
JC501-Q,R
AUDIO-BUFFER 1
IC2A3
M51320P
AV2-OUT-SW
Q2A1
JC501-Q,R
AV2-SW
L-IN
R-IN
SWITCHED-H
VOL
BAL
A
B
MODE


IC2A1 LA7952 VIDEO-SW1
Q2B8 YA101-Q,R TRAP-OFF-SW2
Q2B9 JC501-Q,R TRAP-OFF-SW3
Q2C0 JC501-Q,R Y-BUFFER-2
Q2A5 JC501-Q,R VIDEO BUFFER-3
Q2A6 JC501-Q,R 3.58 SW1
Q2A8 JC501-Q,R 4.28 SW1
Q2A9 JC501-Q,R 4.43 SW
Q2B6 JC501-Q,R 4.28 SW2
Q2A7 JC501-Q,R 3.58 SW2
Q2B2 JC501-Q,R TRAP-OFF-SW1
Q2B3 2SC2058S-Q /2SC2724 VIDEO-BUFFER-2
Q3A3 JA101-Q,R VOL-CONT-BUFFER
IC3A1 LA7953 AUDIO-CONTROL
IC3A5 TC40438P /HEF40538P AUDIO-SW
Q3A2 2SC2236-Q,Y 12V-REG
Q3A1 JC501-Q,R 8V-REG
IC3A3 BX7601A
IC3A4 BX7601A
+12V
MUTE


IC2A1 LA7952 VIDEO-SW1
DRIVER
CONT
SW
TV
V/C
Q2B8 JA101-Q.R TRAP-OFF-SW2
Q2B9 JC501-Q.R TRAP-OFF-SW3
Q2C0 JC501-Q.R Y-BUFFER-2
Q2A5 JC501-Q.R VIDEO BUFFER-3
Q2B3 2SC2058S-Q /2SC2724 VIDEO-BUFFER-2
Q2A6 JC501-Q.R 3.58 SW1
Q2A8 JC501-Q.R 4.28 SW1
Q2A9 JC501-Q.R 4.43 SW
Q2B6 JC501-Q.R 4.28 SW2
Q2A7 JC501-Q.R 3.58 SW2
Q2B2 JC501-Q.R TRAP-OFF-SW1
Q3A3 JA101-Q.R VOL-CONT-BUFFER
IC3A1 LA7953 AUDIO-CONTROL
IC3A5 TC40538P /HEF40538P AUDIO-SW
IC3A3 BX7601A
Q3A2 2SC2236-O.Y 12V-REG
Q3A1 JC501-Q.R 8V-REG
IC3A4 BX7601A
+12V
MUTE


Q2B4
JC501-Q.R
C1-SW
Q2B5
JC301-Q.R
C2-SW
Q2B0
JA101-Q.R
Y-BUFFER-1
IC2A2
MB1321P
VIDEO-SW2
Q6A3
JA101-Q.R
C-BUFFER-2
BX7601A GEQ.L
BX7601A GEQ.R
IC3A2
LC7523
GEQ-VOL
RESISTOR NETWORK ANALOG SW
LATCH
SHIFT
CONTROL
VOL
L-IN
R-IN
B
A
R-OUT
L-OUT
N.C.
GRAEQ.DA
GRAEQ.CL
SP-R
SP-L
SW-C2
SWITCHED-H
Y
SW-C1
VIDEO-IN
VIDEO-OUT
CHROMA
+12
SYNC
PERI-1-H
PERI-2-H
B
G
R
BLK
#21
#11
#10
+21V
PCB-DEFL/REG
AP
⑨1Vp-p(H)
⑯1Vp-p(H)
⑰1.8Vp-p(H)
IC3A3,IC3A4
BX7601A


IC7001 M50541FP
MAIN PICTURE SYNC
MEMORY TIMING GENE
OPERATION CONTROL
MEMORY CONTROL
MEMORY TIMING GENE
SUB PICTURE SYNC
IC7010 M5M4C500L-10
INSTRUCTION DECODER BUFFER
DECODER (1/256)
INPUT AD-DRESS COUN-TER IRC(9)
ADDRESS SELECTOR (256)
DATA REGISTER (256X6)
INPUT BUFFER
256X6
A8
RAM (320X256X6)
DECODER
RAM ADDRESS COUNTER, REG.(9)
IC7007 LA7950 50/60HZ IDENT
COUNTER
IDENT
SYNC. SEP.
COMPARATOR
Q7017 JA101-Q, R MAIN-V-BUFFER
IC7005 M52684AP MAIN-AFC
Q7002 JC501-Q, R PAL/443NTSC-SW
Q7003 JC501-Q, R 358NTSC-SW
Q7004 JC501-Q, R SECAM-SW
Q7005 JC501-Q, R XTAL-SW-2
Q7006 JC501-Q, R XTAL-SW-1
BELL FILTER
NTSC VCO
PAL VCO
SECAM ID
IC7008 TDA4556 MSD
PCB-SIGNAL
FP


6
7
8
9
10
11
FP
PCB-SIGNAL
FH
PCB-DEFL/REG
YC
CC
CHLD-H
YD
+12
L7402
10μH
C7113
50V
10μ
R7105
22K
R7108
3.3K
R7107
1K
R7106
3.3K
Q7018
JA101-Q,R
SUB-Y-BUFFER
C7111
2.01
R7103
10K
R7104
1K
R7420
180
1W
R7001
82
5W
IC7004
μPC7805H
REG
C7062
35V
100μ
C7063
25V
330μ
LC7003
DSS306-
56F2103N100
LC7004
DSS306-
56F2103N100
LC7005
DSS306-
56F2103N100
LC7006
DSS306-
56F2103N100
LC7007
DSS306-
56F2103N100
D7004
1N4148
R7004
100K
R7003
47
R7017
5.6K
R7015
1K
R7014
100
R7016
1.5K
Q7007
JC501-Q,R
MAIN-SYNC
BUFFER1
Q7008
JC501-Q,R
MAIN-SYNC
BUFFER2
R7416
10K
R7415
100
C7411
62
Q7022
JA101-C,R
H-PHASE
R7417
2.2K
C7064
50V
.1
R7093
1K
R7094
1K
C7067
16V
100μ
LC7008
C7068
50V
.1
R7005
22K
L7008
3.3μH
Q7015
JA101-Q,R
5V-POWER-SW
+12
IC7001
M50541FP
PIP-CONTROLER
C7066
47
CH
C7069
16V
100μ
C7070
50V
.1
C7071
B-1000
C7072
CH
C7073
CH
C7074
CH
Q7021
JC501-Q,R
SUB-Y-AMP1
Q7009
JA101-Q,R
SUB-Y-AMP2
R7111
2.7K
R7113
1K
R7116
100
R7081
1K
R7112
1.5K
R7114
680
R7115
680
C7412
35V
47μ
LF7001
1H
L.P.F
L7007
10μH
C7048
50V
100μ
L7009
1μH
L7010
1μH
L7011
1μH
IC7010
M5M4C500L-10
VIDEO MEMORY
R7031
47K
R7033
1K
R7032
1K
R7034
1K
R7035
1K
C7061
500V
2700
C7076
220
C7075
150
R7036
R7091
4.7K
R7078
R7077
5.6K
R7084
3.3
C7079
C7080


PCB-SIGNAL
PCB-DEFL/REG
Q7016 JA101-Q.R SUB-Y-BUFFER
IC7004 μPC7805H REG
Q7007 JC501-Q.R MAIN-SYNC BUFFER1
Q7008 JC501-Q.R MAIN-SYNC BUFFER2
Q7022 JA101-Q.R H-PHASE
IC7001 M50541FP PIP-CONTROLER
Q7015 JA101-Q.R 5V-POWER-SW
Q7021 JC501-Q.R SUB-Y-AMP1
Q7009 JA101-Q.R SUB-Y-AMP2
IC7010 M5M4C500L-10 VIDEO MEMORY
Q7010
Q7011


12
13
14
15
16
17
PCB-PIP
IC7002
M74HCU04P
MAIN-OSC(30MHZ)
IC7401
M50253P
EXPANDER
IC7003
SN74S124N
SUB-OSC(5MHZ)
CH1LD-H
DIGITAL GND
DATA
CLK
PCB-SIGNAL [SM]
PTP
PCB-SIGNAL [FK]
FAST-SW
R-Y
B-Y
Y
PCB-YUV [YP]
STBL
SBC/A
SBT/B
SGL/MUT
Q7020
JC501-Q.P
PIP-INVERTER


OPERATION CONTROL
MEMORY CONTROL
MEMORY TIMING GENE
SUB PICTURE SYNC
IC7010 M5M4C500L-10
DECODER (1/256)
ADDRESS SELECTOR (256)
DATA REGISTER (256X6)
RAM (320X256X6)
INSTRUCTION REGISTER
INSTRUCTION DECODER
TIMING GENE
IC7008 TDA4556 MSD
Q7002 JC501-Q,R PAL/443NTSC-SW
Q7003 JC501-Q,R 358NTSC-SW
Q7004 JC501-Q,R SECAM-SW
Q7005 JC501-Q,R XTAL-SW-2
Q7006 JC501-Q,R XTAL-SW-1
IC7006 M52684AP SUB-AFC
Q7010 JA101-Q GATE-PULSE AMP
Q7016 2SK656 SUB-SYNC BUFFER
IC7008 TDA4556
FEEDBACK
GAIN CONTROLLED CHROMINANCE AMPLIFIER
ACC DEMODULATOR
SYSTEM CONTROL STANDARD SCANNING
FORCED STANDARD SETTING
SECAM V/H/+V
IDENTIFICATION
PAL/NTSC
HUE CONTROL NTSC±30°
OSCILLATOR AND 1:2 DIVIDER (PAL/NTSC)
BURST BLANKING
CHROMINANCE OUTPUT STAGE
MATRIX SECAM LIMITER PERMUTATOR
SECAM REFERENCE
DEMODULATOR
SECAM DEEMPHASIS BLANKING COLOUR KILLER
SERVICE
SANDCASTLE PULSE DETECTOR
PAL/SECAM
NTSC
IC7005.IC7006 M52684AP
H VCO 32fH
H Sync Sep

Q7007
JC501-Q.R
MAIN-SYNC
BUFFER1

Q7008
JC501-Q.R
MAIN-SYNC
BUFFER2

Q7022
JA101-Q.R
H-PHASE

IC7001
M50541FP
PIP-CONTROLER

Q7015
JA101-Q.R
5V-POWER-SW

Q7021
JC501-Q.R
SUB-Y-AMP1

Q7009
JA101-Q.R
SUB-Y-AMP2

IC7010
M5M4C500L-10
VIDEO MEMORY

Q7010
JA101-Q.R
GATE-PULSE
AMP-1

Q7011
JA101-Q.R
GATE-PULSE
AMP-2

Q7013
JA101-Q.R
.6M L.P.F
R-Y BUFFER

Q7014
JA101-Q.R
.6M L.P.F
B-Y BUFFER

IC7009
M52686P
A/D-CONVERTER

Q7012
JA101-Q.R
VD-INVERTER

Q7001
JC501-Q.R
A/D BLACK-LEVEL
COMPENSATION

006 M52684AP

H VCO
32fH

AFC

Horizontal
Count Down

H Sync Sep

V Sync Sep

43 0.2Vp-p(H)

42 5.2Vp-p(H)

IC7009 M52686P

BUFFER

COMP

EN-
CODER


CRT-RUG
CX
PCB-PCC/DBF
IC5001
TEA2031A
E/W OUT
PCC-PHASE
H-WIDTH
PCC-AMP
PCC-OUT
DCF
ACL
29V
V-RANP
50/60HZ
V-NF
H-PARA
V-PARA
12V
AFC
PCB-DEFL/REG
PZ1
PZ2
PZ3
PCB-PIP
PCB-DCF
PCB-MAIN
Q5006
JC501-Q.R
DCF SW
Q5503
2SC4450MSB-PE
DBF-OUT
Q5504
JC501-R
DBF DRIVE1
Q5502
JC501-Q.R
DBF DRIVE2
Q5501
JC501-Q.R
V-PARABOLIC GEN
T5501
PCB-DEFL /REG
DV
1000V
FBT
DF
PCB-POWER-SUB
NEUTRAL
(BLUE)
AC230V
50HZ
LIVE
(BROWN)
PX
PY
PL
PC
PCB-ADG
PG
IC9A1
M51848P
VCC
VREF
THRESHOLD
TRIGGER
POWER RESET
COMPARATOR
FLIP FLOP
OUTPUT STAGE
RESET
OUT-PUT
DIS-CHARGE
ADG-COIL


6
7
8
9
10
11
PCB-CONTROL
PJ
PCB-DG
PT
PCB-SIGNAL
PB
PCB-PIP
FH
PCB-DEFL/REG
PZ1
PCB-DCF
LP
12V
5V
30V
50/60HZ
DCF:ON/OFF
PCB-MAIN
PD
POWER-ON
5.7V
PZ2
PZ3
NEUTRAL
(BLUE)
LIVE
(BROWN)
PL
S991
(V)
PC
RP901
PG
AP
PCB-AV
PF
PCB-SIGNAL (V)
SG
DF2
PCB-CRT
SCREEN
F1
F2
EHT
ADG-COIL
IC901
TEA2261
SLAVE-REG-OUT
Q901
2SD1887
REG-OUT
Q902
UC501-Q-R
SLOW-START
T901
T902
T552
ACL
N.C
N.C
H-DRIVE
FBP
V-DRIVE
12V


PCB-CONTROL
PJ
PCB-DG
PT
PCB-SIGNAL
PB
12V
ACL
N.C
N.C
H-DRIVE
FBP
V-DRIVE
12V
N.C
V-SYNC
PCB-PTD
FH
12V
PCB-DCF
LP
5V
30V
50/60HZ
DCF:ON/OFF
5V
PCB-MAIN
PD
POWER-ON
5.7V
12V
NEUTRAL
(BLUE)
(V)
(BROWN)
PL
PC
RP501
IC901
TEA2261
SLAVE-REG-OUT
Q901
2SD1887
REG-OUT
Q902
JC501-Q,R
SLOW-START
Q953
2SB1135-R,S
12V REG
IC953
M5237L
ERROR AMP
IC951
SI-3050C
5V REG
Q950
2SA950-Y
POWER-SW-1
T901
T902
T952
AP
PCB-AV
PCB-SIGNAL(V)
PF
PCB-CRT
SG
DF2
SCREEN


12
13
14
15
16
17
PCB-VMCRT
PA
TP2
PCB-DEFL/REG
N.C
V-SYNC
130V
12V
2.6Vp-p(V)
54Vp-p(V)
IC451
LA7838
V-OUT
Ramp Gen
Vert Drive
Vert TRIG INPUT
One Shot Multi
50/60 Hz
Vert OUT
Pump Up
+12V
11.8V
3.9V
5.9V
6V
.1V
6.1V
5.5V
26.5V
1.3V
0V
15.5V
25.5V
V.HIGHT
V.POS
V.LIN
PCB-SWIFTEXT
TD
IC952
μPC78M05H
5V REG
Q451
JC501-Q,R
EW-BUFFER
0.9Vp-p(H)
Q954
JC501-Q,R
POWER-SW-3
Q952
2SB1135-R,S
29V REG
Q551
2SC2482
H-DRIVE
210Vp-p(H)
IC955
M5237L
ERROR AMP
Q951
JC501-Q,R
POWER-SW-2
PCB-PCC/DBF
PZ1
29V
ACL
IC950
TEA5170
MASTER
-REG-
Q552
2SD1879
H-OUT
V-NF-TN


PCB-DEFL/REG
LP
+12V
GND
+5V
L5012 10μH
SWITCHED 5V
L5002 100μH
IC6001 CXL1009P CCD SIGNAL PROCESSER
SYNC TIP CLAMP CIRCUIT
AUTO BIAS CIRCUIT
CLOCK DRIVER
TIMING GENERATOR
OUT PUT
Q6003 JA101-Q, R BUFFER-3
Q6001 JC501-Q, R BUFFER-1
Q6002 JC501-Q, R BUFFER-2
Q6004 2SC2724-E / 2SC2058S-Q OSC-BUFFER
X6001 NR-18-21.3254HZ
IC6002 BX6387 AMP
VR6001 B-1K
LEVEL-1
LF6001 H314LSKS-2422WAD
1Vp-p(H)
IC6004 KIC-BPF2 INVERTER
DF5001 D.F 140ns
VR6003 B-1K
PHASE-1
+12V
DCF-H
Comb ON/OFF SW


PCB-SIGNAL
DA
DCF-H
GND
R6030 22K
R6031 15K
Q6007 2SC501-Q, R DCF-SW
12.4V
0V
R6038 470
C6053 50V 10μ
C6052 Z-.01
IC6012 TC4053BP /HEF4053BP DCF SW
12.4V 5.3V 6V 5.3V 5.3V 6V 0V 0V 0V
R6035 47K
R6036 47K
R6037 47K
R6033 5.6K
R6034 5.6K
C6054 50V 10μ
C6051 50V 47μ
CompIN
GND
C-OUT
Y-OUT
PCB-AV
AK
Comb ON/OFF SW
C6044 16V 47μ
IC6010 CX22013 V-CORRELATION
V-APA
+12V
IC6011
R6028 2.2K
R6029 2.2K
6V
0V
C6049 Z-.01
C6050 50V 10μ
TP-G


PCB-TERMINAL
LD2
PCB-NICAM
Q3008
JC501-Q, R
L-BUFFER
Q3007
JC501-Q, R
R-BUFFER
11.7V
5.9V
5.2V
15.3V
R3072 1K
R3074 1K
R3071 1K
SD
PCB-NICAM
SN
PCB-NICAM
AU2
PCB-NICAM
LD2
PCB-TERMINAL
Q3803


PCB-NICAM
LD2
Q3008
JC501-Q.R
L-BUFFER
Q3007
JC501-Q.R
R-BUFFER
R3072 1K
R3074 1K
R3071 1K
R3073 1K
11.7V
5.9V
5.2V
5.3V
L
R
SD
PCB-TERMINAL
IC3009
TL082CP
RIPPLE-
FILTER
VCC
GND
0V
C3055 25V 47μ
R3046 47K
R3047 47K
C3052 16V 470μ
R3109 100
R3055 100
R3078 100
R-IN
NICAM-L
MUTE
GND
+12V
ST
PCB-NICAM
SN
AU2
LD2
PCB-TERMINAL
N.C.
D3203 1N4148
D3204 1N4148
D3205 1N4148
R3208 5.6K
R3209 5.6K
R3210 5.6K
Q3201
JC501-Q.R
NICAM-SW
R3203 56K
D3202 1N4148
R3202 5.6K
D3201 1N4148
Q3202
JC501-Q.R
MUTE-SW
R3204 10K
3.75V
2.8V
2.2V
R3201 100
R3205 22K
R3206 220K
R3207 68K
C3201 50V 10μ
C3202 25V 2.2μ
R-OUT
+12V
L-IN
GND
R-IN
L-OUT
R-OUT
L'-IN
R'-IN
MUTE1
NICAM-IF
+12V
+5V
NICSM-L
MUTEO
ST
MONO1
MONO2
SEL1
SEL2
NA
NB
PCB-SIGNAL


⚠ TRANSMITTER REMOCON
IC 1
μPD17203GC
REM-MICON
Q1
2SC2982B/C
OR2SC3443F/G
REM-SW
IC2
RH5VA26AA
⚠ PCB-LED
⚠ PCB-PREAMP
⚠ PCB-E
PCB-DEFL/REG
PCB-SIGNAL
(S-H)
EA
LD
ON-TIMER DISP
STANBY DISP
UNIT PREAMP


PCB-SIGNAL
LD
RA
EP
PCB-DEFL/REG
PJ
NS
PCB-CONTROL
PCB-YCSW
PCB-AV
PCB-AOG
PCB-SIGNAL
KY
S7Z0
S7Z1
S7Z2
DEGAUSS-SW
S7Z5
SP-SW
S7Y1
VIDEO Func
S7Y2
AUDIO Func
S7Y3
PDW
S7Y4
ANA+
S7Y5
ANA-
S7Y7
CH+
S7Y8
CH-
J7Y1
J7Y2
J7Y3
Q7Y1
JC501-Q, R
S1-SW
Q7Y2
JC501-Q, R
S1-Y-BUFFER
S1/S1'
LC7Y1
4.43MHZ
R-OUT
L-OUT
+5V
PCB-YCSW
PCB-CONTROL
PCB-AV
IC2P2
HEF4053BP
AUDIO-SW
IC2P3
HEF4053BP
Y/C-SW


⚠ PCB-VMCRT
⚠ PCB-EPJ
Q651 2SC2688-M, N R-OUT-1
Q658 2SC2482 R-OUT-2
Q655 2SC2058S-Q R-AMP
Q652 2SC2688-M, N B-OUT-1
Q659 2SC2482 B-OUT-2
Q656 2SC2058S-Q B-AMP
Q653 2SC2688-M, N G-OUT-1
Q660 2SC2482 G-OUT-2
Q657 2SC2058S-Q G-AMP
Q654 JA101-Q, R DRIVE-REF
Q8021 2SC3065-F VM CONT-2
Q8007 JC501-Q, R VM BAFFER
Q8005 JC501-Q, R VM AMP
Q8003 JC501-Q, R VM DRIVE1
Q8001 2SB940-P VM-OUT1
Q8009 JC501-Q,R VM CONT-1
Q8008 JC501-Q, R DIFF1
Q8006 JC501-Q, R DIFF2
J601
V271 ⚠ M89KCW11X
⑱170Vp-p(H)
⑲130Vp-p(H)
⑳150Vp-p(H)
H. V.
FOCUS1
FOCUS2
SCREEN
R-DRIVE
B-DRIVE
G-DRIVE
R-SCREEN
B-SCREEN
G-SCREEN
PCB-SIGNAL
PCB-DEFL/REG
PCB-EPJ
CP-ASSY
+12
+130V
+230V
VIDEO
N. C



⑳1Vp-p(H) ㉒0.7Vp-p(H) ㉓0.9Vp-p(H) ㉔0.9Vp-p(H) ㉕0.7Vp-p(H)

㉖1.1Vp-p(H) ㉗1Vp-p(H) ㉘0.8Vp-p(H) ㉙0.8Vp-p(H)


5.7V
12V
NEUTRAL
(BLUE)
LIVE
(BROWN)
PL
PC
AP901
IC901
TEA2261
SLAVE-REG-OUT
Q901
2SD1887
REG-OUT
Q902
UC501-Q,R
SLOW-START
Q953
2SB1135-A,S
12V REG
IC953
M52371
ERROR AMP
IC951
ST-3050C
5V REG
Q950
2SA950-Y
POWER-SW
T901
T902
T951
T952
AP
PCB-AV
PCB-
SIGNAL (V)
PCB-
CRT
PCB-
DBF
PCB-VMCRT
PCB-LED
TP1
EA
SG
DF
DF1
DF2
PS
SCREEN
F1
F2
EHT
HEATER
DBF
AFC
220V
(V)
IC901 TEA2261
INTERNAL BIAS
VCC MONITORING
VREF(2.49V)
OVERVOLTAGE DETECTION
MODULATOR LOGIC
PRIMARY PULSES
AUTOMATIC BURST GENERATION
IS LOGIC
REGULATION PULSES
LOGIC PROCESSOR
POSITIVE OUTPUT STAGE
NEGATIVE OUTPUT STAGE
DEMAGNETIZATION SENSING
REPETITIVE OVERLOAD PROTECTION
CURRENT LIMITATION
OSCILLATOR
SECONDARY PULSES
OUT
GND



CT-37C2EDT(3/5)


PCB-DEFL/REG
DV
1000V
FBT
DF
Q5503
2SC4450MSB-RE
DBF-OUT
Q5504
JC501-R
DBF DRIVE1
Q5502
JC501-G.R
DBF DRIVE2
Q5501
JC501-G.R
V-PARABOLIC GEN
H-PARA
V-PARA
12V
AFC
PZ3
PCB-DEFL/REG
PZ3
T5501
NEUTRAL
(BLUE)
LIVE
(BROWN)
S991
PCB-POWER-SUB
AC230V
50HZ
PIX
PY
PIC
PCB-ADG
PS
PC
ADG-COIL
PE
PCB-CONTROL
PT
PCB-DEFL/REG
IC9A1
M51848P
VCC
VREF
THRESHOLD
TRIGGER
GND
RESET
OUT-PUT
DIS-CHARGE
COMPARATOR
FLIP FLOP
OUTPUT STAGE
POWER RESET
TIMER
IC950 TEA5170
OSCILLATOR
LOGIC (SYNCHRO)
SOFT START AND DUTY CYCLE LIMITING
ERROR AMPLIFIER
POWER OUTPUT STAGE
VCC MONITOR
IC951
SI-3050C
PRE-REG
OUT-OUT ON/OFF CONTROL
PROTECTION
DRIVE
ERROR AMP
REF
INTERNAL BIAS
MODULATOR LOGIC
AUTOMATIC BURST GENERATION
PRIMARY PULSES
DEMAGNETIZATION SENSING
SOFT START
OSCILLATOR


5.7V
12V
PCB-DEFL/REG
PZ3
NEUTRAL
(BLUE)
LIVE
(BROWN)
S991
PL
PC
IC901
TEA2261
SLAVE-REG-OUT
Q902
JC501-Q,R
SLOW-START
Q901
2SD1887
REG-OUT
T901
T902
IC901 TEA2261
ERROR AMPLIFIER
INTERNAL BIAS
VCC MONITORING
OVERVOLTAGE DETECTION
MODULATOR LOGIC
AUTOMATIC BURST GENERATION
PRIMARY PULSES
REGULATION PULSES
IS LOGIC
LOGIC PROCESSOR
POSITIVE OUTPUT STAGE
NEGATIVE OUTPUT STAGE
DEMAGNETIZATION SENSING
REPETITIVE OVERLOAD PROTECTION
CURRENT LIMITATION
OSCILLATOR
SECONDARY PULSES
AP
PCB-AV
PCB-SIGNAL (V)
PF
PCB-CRT
SG
DF2
SCREEN
F1
F2
EHT
PCB-DEF
DF
DF1
HEATER
PCB-VMCRT
PS
220V
TP1
EA
PCB-LED
LD
ADG-COIL
PCB-CONTROL
PE
PCB-DEFL/REG
PT


IC7001
M50541FP
PIP-CONTROLER
Q7007
JC501-Q.R
MAIN-SYNC
BUFFER1
Q7008
JC501-Q.R
MAIN-SYNC
BUFFER2
Q7022
JA101-Q.R
H-PHASE
Q7015
JA101-Q.R
5V-POWER-SW
Q7021
JC501-Q.R
SUB-Y-AMP1
Q7009
JA101-Q.R
SUB-Y-AMP2
IC7010
M5M4C500L-10
VIDEO MEMORY
Q7010
JA101-Q.R
GATE-PULSE
AMP-1
Q7011
JA101-Q.R
GATE-PULSE
AMP-2
Q7013
JA101-Q.R
.6M L.P.F.
R-Y BUFFER
Q7014
JA101-Q.R
.6M L.P.F.
B-Y BUFFER
Q7012
JA101-Q.R
VD-INVERTER
IC7009
M52686P
A/D-CONVERTER
Q7001
JC501-Q.R
A/D BLACK-LEVEL
COMPENSATION
+12
+5


Horizontal
Count Down
AFC
V Sync Sep


43 0.2Vp-p(H)

42 5.2Vp-p(H)


IC7009 M52686P
BUFFER
0.75 Vcc
0.55 Vcc
COMP
EN-CODER
CL VIDEO
CL Y
CL R-Y
CL B-Y


DIGITAL GND
STILL
SBC/A
SBY/B
SGL/MUL
PIP
CHILD-H
R7095 10K
R7096 22K
R7097 56K
Q7020 .6V 0V 0V
Q7020 -JC501-Q.A PIP-INVERTER
R7086 330
R7090 100
PIP
FAST-SW
R-Y
B-Y
Y
PCB-SIGNAL
PCB-YUV
C7087 SR25V .1
C7088 16V 100μ
L7015 1μH
C7089 SR25V .1
C7090 35V 47μ
R7088 10K
R7087 10K
C7099 50V 10μ
C7100 50V 10μ
LC7009 DS330F- 548101M100
LC7010 DS330F- 548101M100
LC7011 DS330F- 548470M100
C7101 2-.01
IC7011 M52882P D/A-CONVERTER
TTL to ECL
Ref Voltage
C7102 50V 10μ
C7104 50V 10μ
C7103 2-.01
CLOCK GENERATOR
LATCH
OUT-PUT BUFF-ER
㊴ 0.7Vp-p(H)
㊵ 0.9Vp-p(H)
㊶ 0.9Vp-p(H)
IC7401 M50253P
INPUT CONTROL
12BIT SHIFT REGISTER
LATCH
BUFFER


PCB-SWIFTEXT
PCB-DEFL/REG
IC7701
SAA5191
PULSE GENERATOR
HORIZONTAL PHASE DETECTOR
VOLTAGE CONTR. OSCILLATOR
SENSE NO INPUT
ADAPTIVE DATA SLICER
LATCHES
ADAPTIVE SYNC SEPARATOR
DUAL POLARITY BUFFER
CLOCK PHASE DETECTOR
SENSE NO LOAD
SENSE EXTERNAL DATA
PHASE SHIFTER
GAIN SWITCH
HF LOSS COMPEN-SATOR
OSCILLATOR /2
IC7702
SAA9042
DAC
DATA ACQUISITION
I²C INTERFACE & CONTROL
DISPLAY
OUTPUT BUFFERS
ACQUISITION TIMING
TIMING CHAIN
MEMORY INTERFACE
18 to 26
30 to 33
IC7703
TC514256AP
DATA INPUT BUFFER
DATA OUTPUT BUFFER
OE
CLOCK NO.2 GENERATOR
ADDRESS BUFFER
COLUMN DECODER
REFRESH CONTROL
SENSE AMP I/O GATE
512×4
REFRESH CONTROL
ROW ADDRESS BUFFER
ROW DECODER
512
MEMORY ARREY
CLOCK NO.1 GENERATOR
SUB STRAIGHT
TD
TD
R7750
4.7K
R7729
27K
8.7V
3V
Q7705
JC501-Q.R
O/E-SWITCH
0V
R7730
56K
IC7702
SAA9042P/A
DECODER
Q7713
JA101-Q.R
H-SYNC-BUFFER
R7740
10K
5V
2V
4.7V
R7741
6.8K
C7729
100
SL
R7742
2.7K
C7738
.027
C7730
50V
10μ
L7703
10μH
C7736
C7732
100
SL
PL
SCL
SDA
VSA
HSA
VSD
HSO
LL3A
BLK
R
G
B
CDAC
VSS0
VDD
VSS2
LL3O/
LL1.5O
A0
A1
A2
O/E
TTD
TTC
SAND
INT
VSS3
VSS1
D0
D1
D2
D3
R/W
CAS
RAS
A8
A7
A6
A5
A4
A3
IC77
TC51
256K
I/O.1
I/O.2
WRITE
RAS
N.C
A0
A1
A2
A3
VDD
C7734
L7704
10μH
C7702



IC7704 P83C528



IC7705
X24C04P






IC3006
TD6710AN
IC3003
TA8662N
QPSK SIGNAL AMP
IC3002
AN608P
QPSK SIGNAL AMP
IC3001
AN608P
LC3001
Q3001
JC501-Q, R
BUFFER
IC3003
TA8662N
QPSK DECODER
Q3002
2SC2274-F
10V-REG
D3001
6DA05-10C
IC3004
TC6011N
NICAM DECODER
IC3005
HM6264ALSP-10I2
S-RAM
PCB-TERMINAL
SN
VSS
RDATA
RCLK
MCLK
TEST1
TEST2
RESET
SFTCLK
LRCLK
DADATA
MUTEO
MUTEI
DDATA
DGATE
CDATA
CGATE
SEL1
SEL2
PERR
SERR
VCC
VDD
STEREO
MONO1
MONO2
WEN
I/O1
I/O2
I/O3
GND


IC3007 AFL87F14000A11 L.P.F-L
IC3008 AFL87F14000A11 L.P.F-R
IC3005
TD6710AN
DAC
Q3003
JC501-Q.R
L-MUTE
Q3006
JC501-Q.R
SW
Q3004
JC501-Q.R
R-MUTE
IC3014 M5201L AUDIO-SW-L
IC3015 M5201L AUDIO-SW-R
IC3005 HM6264ALSP
Memory Matrix 256X256
ROW Decoder
Column I/O
Column Decoder
INPUT Data Control
Timing Pulse Con
Read Write CONTROL
SEL2
+5V
SEL1
L-IN
GND
AU2
PCB-TERMINAL


IC7705
X24C04P
EEPROM
IC7701
SAA5191
VIP
Q7704
JC501-Q.R
VIDEO BUFFER
IC7704
P83C528/XXX
MICON
IC7703
TC514256AP
256K4 DRAM
13.5MHZ ADJ
5V
12V
TP1
H-SYNC-IN
PCB-SIGNAL
TE
-Q.R
WITCH



CT-37C2EDT(4/5)